



Topline 510.350 DGH

Operating instructions

**Before transporting and using the machine,
please read the instructions thoroughly!**

Service and information

Your BOMAR dealer:

Direct BOMAR contact:

BOMAR spol. s r.o.
Těžební 1236/1
62700 Brno
Czech Republic, EU

telefon: +420 – 533 426 100
fax: +420 – 533 426 109
e-mail: info@bomar.cz
www: <http://www.bomar.cz>

We are available:

Mondays to Fridays

7⁰⁰ – 16⁰⁰

Version:

1.01 / March 2016
rev. 1

BOMAR, spol. s r.o. © – Subject to modifications and amendments.

EC Declaration of Conformity

1) We:

BOMAR, spol. s r.o.
Těžební 1236/1
627 00 Brno, Czech Republic
 Id. No: 48908827
declare herewith

that the following designated device based on its conception and construction as well as the design launched by us meets the relevant basic safety requirements of the decrees of the government. This statement applies exclusively to the machine device in conditions in which it was brought to the market. It does not apply to parts subsequently added by the end user or to modifications performed subsequently by the end user. In the event of any device modification not approved by us this declaration shall lose its validity

Name: Band Saw
Type : Topline 510.350 DGH
Serial number:
Manufacturer BOMAR, spol. s r.o., Těžební 1236/1, 627 00 Brno
Product data
Determination: for cross dividing and cutting of rolled and towed bars and profiles made of steel, stainless steel, non-ferrous metals and plastics
Description: Stand, table, cutting unit with the arm, saw band and drive, hand clamping device, cooling system, machine control
 Pneumatic ☒ YES ☐ NO Hydraulic ☒ YES ☐ NO Control system ☒ YES ☐ NO
Technical data: Cutting rate 20-120 m.min-1
 Cutting angle - 60° až 45°
 Total dimensions in mm (lxwxh) 2279x1425x1890
 Total power requirement 6 kW
 Weight 1050 kg

Documentation:
 Technical documentation for this machine device was elaborated in compliance with Government regulation no. 176/2008, Annex 7, part A.

The device meets relevant requirements of the given directives: 2006/42/ES
 2004/108/ES

The applied harmonized standards, National standards and technical specifications:
 ČSN EN ISO 12100:2011 ČSN EN 13898+A1:2009 ČSN EN ISO 13857:2008
 ČSN EN ISO 4413:2011 ČSN EN 61000-6-2 ed.3:2006 ČSN EN 60204 -1 ed.2+A1:2009
 ČSN EN 55011 ed.3+A1:2011 ČSN EN 61000-6-4 ed.2+A1:2011

The product is safe on condition of the common and determined usage.

The conformity judging was performed according to §12, par. 3, let. a), of the Law no. 22/1997 Coll. as amended.
 The declaration of conformity was carried out in the cooperation with the TÜV SÜD Czech s.r.o. 2), Novodvorská 994, 142 21 Prague 4 – Czech Republic, Identification number: 63987121 - Inspection body no. 4002.

The inspection certificate no **06.759.511 r1** was issued

Brno, 22.2.2016
 Point of issue, datum

BOMAR, spol. s r.o.
Těžební 1236/1, 627 00 Brno
Czech Republic
IČO: 48908827
DIČ: CZ48908827


Alfred Pichlmann, Managing Director
 Name and function of the responsible subject,
 signature

Person authorized to complete the technical documentation: BOMAR, spol. s r. o., Těžební 1236/1, 627 00 Brno

- 1) Name, address and identification number of the subject issuing the conformity declaration (producer of importer)
- 2) The authorized or accredited body co-operating on the conformity judging

!

If the equipment is installed without safety equipment offered by BOMAR, spol. s ro or its agents and used by the customer (or buyer) then EC declaration loses validity.
 EC Declaration of conformity is valid only if customer (buyer) installed the BOMAR safety equipment with the machine or with some other with equivalent safety device in accordance with current applicable regulations and standards.
 All machine elements and components that were built into the device by BOMAR, spol. s ro have been declared "identical" to a safety device, as offered by BOMAR, spol. s ro or its agents.

Content

1. BEZPEČNOSTNÍ POKYNY/ SICHERHEITSHINWEISE/ SAFETY NOTES.....9

1.1. Machine determination.....	11
1.2. Protective suit and personal safety.....	11
1.3. Safety notes for machine operator.....	12
1.4. Safety notes for the servicing and repairs.....	13
1.5. Safety instructions for cooling system.....	13
1.5.1. Instructions for first aid.....	13
1.6. Safety notes for the servicing and repairs of the hydraulic unit.....	13
1.7. Safety machine accessories.....	14
1.7.1. Total Stop.....	14
1.7.2. Saw arm cover.....	14
1.7.3. Saw band stretching and rupture inspection.....	15
1.7.4. Band saw covers.....	15
1.7.5. Brush cover.....	15
1.8. Umístění štítku stroje / Maschinenschild position / Position of machine label.....	16
1.9. Umístění bezpečnostních značek / Verteilung der Sicherheitszeichen / Position of safety symbols.....	17

2. DOKUMENTACE STROJE/ DOKUMENTATION DER MASCHINEN/ MACHINE DOCUMENTATION/19

2.1. Technická data / Technische Daten / Technical data.....	21
2.2. Rozměrové schéma / Aufstellzeichnung / Installation diagram.....	22
2.3. Popis / Beschreibung / Description.....	23
2.4. Transportation and stocking.....	24
2.4.1. Conditions for transportation and stocking.....	24
2.4.2. Transport and stocking preparations.....	24
2.4.3. Transport and stocking.....	24
2.4.4. Transportní schéma / Transport schema / Transport scheme.....	25
2.5. Activation.....	26
2.5.1. Machine working conditions.....	26
2.6. Band saw unpacking and assembling.....	26
2.6.1. Machine installing and levelling.....	26
2.6.2. First run of the power pack.....	27
2.6.3. Einfüllung des Hydraulikbehälters.....	27
2.6.4. Verankerungsplan / Grounding plan.....	28
2.6.5. Electrical connection.....	29
2.6.6. Check the direction of the saw band.....	30
2.6.7. Check machine connection into electrical network.....	30
2.6.8. Filling of the cooling system.....	30
2.7. Check machine function.....	30
2.7.1. Machine disposal after lifetime.....	31
2.8. Saw band.....	31
2.8.1. Saw band size.....	31
2.8.2. Selection of the saw band tooth system.....	31
2.8.3. Saw band running-in.....	31
2.8.4. Tables for teeth selection.....	32

3. OVLÁDÁNÍ STROJE/ BEDIENUNG DER MASCHINE/ MACHINE CONTROL33

3.1. Starting the band saw.....	35
3.2. Control panel.....	36
3.2.1. Control panel description.....	37
3.3. Machine referencing.....	39
3.4. Control of the machine Topline 510.350 DGH.....	44
3.4.1. Semi-automatic cycle.....	44
3.5. Control of the machine Topline 510.350 DGH with automatic swivel of the arm angle.....	45
3.5.1. Manual control.....	45
3.5.2. Semiautomatic mode.....	45
3.5.3. Cycle breaking.....	49
3.6. Machine setup.....	49
3.6.1. SERVICE.....	50
3.6.2. SETUP.....	52
3.6.3. Machine error messages.....	54
3.7. Band saw adjusting.....	55
3.7.1. Angular cut setting.....	55
3.7.2. Laserliner – optional accessory.....	56
3.7.3. Saw frame lift stop setting – just for Topline 510.350 DGH.....	56
3.7.4. Adjusting band guides.....	57
3.7.5. Cutting speed adjusting.....	57
3.7.6. Adjustment of pressure to the cut.....	58
3.7.7. Speed adjustment of the arm lowering.....	58

3.7.8.	Brush setting.....	59
3.7.9.	Halogen lighting of working area (optional accessory).....	60
3.8.	Material insertion.....	61
3.8.1.	Handling agent selection.....	61
3.8.2.	Insertion.....	61
3.8.3.	Bundle material cutting.....	61

4. ÚDRŽBA STROJE/ WARTUNG/ MACHINE SERVICE63

4.1.	Saw band dismantling.....	65
4.2.	Saw band installation.....	66
4.3.	Saw band stretching and inspection.....	68
4.4.	Adjusting of the saw band run.....	69
4.4.1.	Saw band run inspection.....	69
4.4.2.	Saw band run setting.....	70
4.5.	Saw frame lower position stop adjustment.....	70
4.6.	Check and adjustment of switches and sensors.....	71
4.6.1.	Setting of the limit switch monitoring the band tightening.....	71
4.6.2.	Check of adjustment of limit switches of the upper and lower position of the arm 72	
4.6.3.	Check of setting of the inductive sensor of the bundler opening.....	75
4.6.4.	Check and adjustment of the vice opening limit switch.....	77
4.6.5.	Check and adjustment of the table position inductive sensors.....	79
4.6.6.	Check of switches and sensors of the arm rotation.....	81
4.7.	Check of the inductive switch to control the thrust to cut.....	86
4.8.	Adjustment of the device for control of thrust to cut.....	86
4.9.	Cooling agents and chips disposal.....	87
4.9.1.	Coolant device inspection.....	87
4.9.2.	Mikroniser(box) – mist lubrication.....	88
4.9.3.	Connecting to the compressed air supply.....	91
4.10.	Chips disposal.....	91
4.11.	Hydraulic, Greases and oils.....	91
4.11.1.	Gearbox oils.....	91
4.11.2.	Lubricant greases.....	92
4.11.3.	Lubrication.....	93
4.11.4.	Hydraulic oils.....	93
4.11.5.	Hydraulic unit service.....	94
4.12.	Machine cleaning.....	95
4.13.	Worn pieces replacement.....	95
4.13.1.	Hard metal guides replacement.....	95
4.13.2.	Hard metal guides adjustment on the machine.....	96
4.13.3.	Saw band guiding pulleys replacement.....	97
4.13.4.	Pushing bearing replacement.....	99
4.14.	Brush replacement.....	101

5. ZÁVADY / STÖRUNGEN TROUBLESHOOTING..... 103

5.1.	Mechanical problems.....	105
5.2.	Electric and hydraulic problems.....	107
5.3.	Hydraulic problems.....	108

6. SCHÉMATA / SCHEMAS / SCHEMATICS..... 111

6.1.	Elektrické schéma / Elektroschema / Wiring diagram.....	113
6.2.	Hydraulické schéma / Hydraulikschema / Hydraulic diagram.....	134

7. VÝKRESY SESTAV PRO OBJEDNÁNÍ NÁHRADNÍCH DÍLŮ / ZEICHNUNGEN FÜR BESTELLUNG DER ERSATZTEILE / DRAWING ASSEMBLIES FOR SPARE PARTS ORDER..... 137

7.1.	TOPLINE 510.350 DGH.....	138
7.2.	Kusovník / Piece list / Stückliste - TOPLINE 510.350 DGH.....	139
7.3.	TOPLINE 510.350 DGH.....	140
7.4.	Kusovník / Piece list / Stückliste - TOPLINE 510.350 DGH.....	141
7.5.	Topline 510.350 DGH s automatickým natáčením úhlu ramene.....	142
7.6.	Kusovník / Piece list / Stückliste - Topline 510.350 DGH s automatickým natáčením úhlu ramene.....	143
7.7.	Topline 510.350 DGH s automatickým natáčením úhlu ramene.....	144
7.8.	Kusovník / Piece list / Stückliste - Topline 510.350 DGH s automatickým natáčením úhlu ramene.....	145
7.9.	Podstavec / Base / Untersatz.....	146
7.10.	Kusovník / Piece list / Stückliste - Podstavec / Base / Untersatz.....	147
7.11.	Brzda / Drive / Antrieb Topline 510.350 DGH.....	148
7.12.	Brzda / Brake / Bremse Topline 510.350 DGH.....	149
7.13.	Doraz / Stop piece / Anschlag Topline 510.350 DGH.....	150
7.14.	Konzola otočná / Turnable consol / Drehkonsole.....	152
7.15.	Kusovník / Piece list / Stückliste - Konzola otočná / Turnable consol / Drehkonsole.....	153
7.16.	Sloup / Pole / Säule.....	154
7.17.	Kusovník / Piece list / Stückliste - Sloup / Pole / Säule.....	155
7.18.	Odměřování / Measuring / Gehrungsmessung.....	156
7.19.	Sloup / Pole / Säule.....	158
7.20.	Kusovník / Piece list / Stückliste - Sloup / Pole / Säule.....	159
7.21.	Svěrák / Vice / Schraubstock.....	160
7.22.	Kusovník / Piece list / Stückliste - Svěrák / Vice / Schraubstock.....	161
7.23.	Válec upínací / Fixing cylinder / Spannzylinder.....	162

7.24. Kusovník / Piece list / Stückliste - Válec upínací / Fixing cylinder / Spannzyylinder.....	163
7.25. Spínač tlakový / Pressure switch / Druckschalter.....	164
7.26. Rameno / Saw arm / Sägerahmen.....	166
7.27. Kusovník / Piece list / Stückliste - Rameno / Saw arm / Sägerahmen.....	167
7.28. Rameno / Saw arm / Sägerahmen.....	168
7.29. Kusovník / Piece list / Stückliste - Rameno / Saw arm / Sägerahmen.....	169
7.30. Převodovka / Transmission / Getriebe.....	170
7.31. Napínání / Tensioning / Spannung.....	172
7.32. Kusovník / Piece list / Stückliste - Napínání / Tensioning / Spannung.....	173
7.33. Vedení pásu / Belt guide / Sägebandführung.....	174
7.34. Kusovník / Piece list / Stückliste - Vedení pásu / Belt guide / Sägebandführung.....	175
7.35. Kostka vodící / Lead cube / Führungsklotz.....	176
7.36. Kusovník / Piece list / Stückliste - Kostka vodící / Lead cube / Führungsklotz.....	177
7.37. Kostka vodící / Lead cube / Führungsklotz.....	178
7.38. Kusovník / Piece list / Stückliste - Kostka vodící / Lead cube / Führungsklotz.....	179
7.39. Pohon / Cart / Wagen.....	180
7.40. Kusovník / Piece list / Stückliste - Pohon / Cart / Wagen.....	181
7.41. Podstavec svěráku / Vice base / Schraubstockuntersatz.....	182
7.42. Kusovník / Piece list / Stückliste - Podstavec svěráku / Vice base / Schraubstockuntersatz.....	183
7.43. Brzda / Brake / Bremse Topline 510.350 DGH.....	184
7.44. Pohon/ Drive/ Antrieb Topline 510.350 DGH-A.....	186
7.45. Kusovník / Piece list / Stückliste - Pohon/ Drive/ Antrieb Topline 510.350 DGH-A.....	187
7.46. Pohon/ Drive/ Antrieb Topline 510.350 DGH-A.....	188
7.47. Kusovník / Piece list / Stückliste - Pohon/ Drive/ Antrieb Topline 510.350 DGH-A.....	189
7.48. Brzda/ Brake/ Bremse Topline 510.350 DGH-A.....	190
7.49. Snímač magnetický/ Magnetic sensor/ Magnetsensor Topline 510.350 DGH-A.....	191
7.50. Pohon/ Drive/ Antrieb Topline 510.350 DGH-A.....	193
7.51. Válec pomocný/ Auxiliary cylinder/ Hilfszylinder Topline 510.350 DGH-A.....	194
7.52. Kusovník / Piece list / Stückliste - Válec pomocný/ Auxiliary cylinder/ Hilfszylinder Topline 510.350 DGH-A195	195
7.53. Ovládací panel / Control panel / Bedienpult.....	196
7.54. Kusovník / Piece list / Stückliste - Ovládací panel / Control panel / Bedienpult.....	197

1. Bezpečnostní pokyny/ Sicherheitshinweise/ Safety notes

The operating instructions must be read by the person, who keeps in touch with the machine before transportation, installation, using, servicing, reparation, stocking or removal!

The operating instructions include relevant information. The operator must familiarise himself with the install and operation, safety notes and machine servicing, because reliability and service life must be reached. The operating instructions must avoid risks, which are linked to work on the machine. Before transporting and using of the machine, please read the instructions thoroughly!

Attention!

*The operating instructions must be available at the machine!
 Keep the operating instructions in good condition!*

1.1. Machine determination

The band saws **Topline 510.350 DGH** are determined for cutting and shortening of rolled bars and drawn bars and profiles from steels, stainless steels, non-ferrous metals and plastics **with cutting angle from -60° to 45°**.

Combustible materials are excepted for cutting! Any other usage and operation outside this range are unauthorized and the manufacturer/supplier does not accept any responsibility for any damages resulting from such misuse. **The operator has full responsibility!**

The machine is equipped with safety and protective guarding for operator and machine protection. Nevertheless, this safety and protective guarding cannot prevent injury. Service personnel must read this chapter and comprehend it, before he starts to work on the machine. **Always keep instructions about work safety!** Service personnel must take into account other aspects of the risk, which refer to the ambient conditions and the material.

1.2. Protective suit and personal safety

Wear tight fitting overalls! Loose fitting clothes may be caught with machine parts and cause serious injury.

Wear protective gloves! Material cuts and saw band have sharp edges and may cause serious injuries.

Attention!

*Gloves you can use only at working material replacement (saw band)! The machine and accessories must be inactive!
 If the machine is running, you must not wear gloves! It is dangerous, because some parts of the machine can catch gloves!*

Wear protective shoes with non-skid soles! The unsuitable shoes may cause balance loss and following injury. Falling work pieces may cause serious injuries too.

Wear protective goggles! Chips and cooling liquid may damage your eyes.

Always wear ear protections! Most of the machines emit up to 80 dB and may damage your hearing.

Do not wear jewellery and always tie back long hair! Moving machine parts can catch jewellery or loose hair and may cause serious injuries.

Operate the machine only when you are fit enough to work. Illnesses or injuries diminish concentration. Avoid machine work, which may compromise the safety of you and your colleagues!

Attention!

Mind the safety signs on the machine. Do not remove or damage them! Keep these labels always readable!

1.3. Safety notes for machine operator

Attention!

**Machine can only be operated by a person older than 18 years!
Machine can be operated only by a person physically and mentally fit for this activity.**

Machine can only be operated only by one person at a time. Machine operator is responsible for other people present near the machine.

The person who is operating the machine using the control elements (control panel and other) must not either alone or with help of other workers move the cut or otherwise machined material at the same time.

Follow the instructions and directives for work safety!

Read the operating instructions before you start to work on the machine! Keep the operating instructions in good condition!

Close covers before starting the machine and check, if the covers are not damaged. Damaged covers must be repaired or replaced immediately. Do not start the machine, if any cover is removed!

Attention!

Do not connect the machine to electricity if the door or any covers are removed. Do not touch the high voltage electrical equipment (transformers, motors, terminals or wiring).

- Check, if the electric cables are not damaged.
- Do not hold or manipulate the material during clamping or cutting!
- Do not operate the buttons and switches on the control panel wearing gloves!
You may press a wrong button.
- Make sure, that there is nobody in the working area of the machine (the working area of the vice, the saw band, the saw arm etc.) during a working cycle and when starting the machine.
- Under no circumstances touch any rotating elements.
- Use the machine only when it is in a good condition!
- Check at least once in a shift, if the machine is not visibly damaged. If you discover any such damage, you must bring the machine to a halt and inform your superior!
- Keep your working area and machine clean and uncluttered! Ensure sufficient lighting in the working area.
- Take off any spilt water or oil from the floor and dry it immediately to avoid a possibility of injury.
- Do not touch the cooling liquid with bare hands!
- Do not adjust the cooling liquid nozzle if the machine is running.
- Do not remove the chips from the working area of the machine, when the machine is running!
- Do not use compressed air for machine cleaning or for chip removal!
- Use protective gear for chip removal!

1.4. Safety notes for the servicing and repairs

Attention!

Only a qualified professional can carry out the servicing and repairs of the electrical equipment! Take special care during the work with electrical equipment. High voltage shock can have fatal consequences! Always follow the work safety instructions! Otherwise, there is possibility of heavy injury!

- Switch off the main switch and lock it, before you start service work! If you have the Practix type of machine, disconnect it from electrical network. This way you eliminate a possibility of starting the machine accidentally.
- Take care when manipulating the frequency converter. It is still energized for 20 minutes after machine shutdown.
- Always adhere to the safety instructions!
- Only an authorized professional can carry out the servicing and repairs.
- For parts replacement, use only those, which are identical with the originals. Otherwise, there is possibility of health hazard.
- Use only recommended types of hydraulic oils, oils and lubricants!
- Do not remove or lock the limit switches or any other safety equipment!
- Any use of the saw, accessories or machine parts other than that intended by BOMAR, spol. s r.o. company is not permitted. The guarantee on this product will be lost afterward and BOMAR, spol. s r.o. takes no responsibility for damage caused.
- Do not turn the machine on if all covers are not in place.

1.5. Safety instructions for cooling system

Attention!

- *When handling the coolant always keep to the work safety directives and instructions of the manufacturer.*
- *When handling cooling agents always wear safety fluid-proof gloves!*
- *Wear protective goggles!*
- *Cooling liquid can get in contact with your eyes and may cause severe injuries*

1.5.1. Instructions for first aid

1. Pull off and safely remove polluted, soaked clothing.
2. If inhaled, go outside on fresh air or look for first aid treatment.
3. Wash with water and eventually treat with crème any points of contact with the skin.
4. Rinse your eyes with water and seek out a doctor.
5. If swallowed, drink a lot of water and induce vomiting. Look for medical help

1.6. Safety notes for the servicing and repairs of the hydraulic unit

Compliance with the principles of cleanliness is a basic requirement for trouble-free operation of hydraulic equipment. Hydraulic components are high precision products, and any contamination leads to a reduced lifetime or even malfunction. The consequences are very difficult and expensive to remove.

Always use clean tools. Parts and fasteners, which are a part of hydraulic circuit, are never to be put on a dirty surface. The best cleaning agent is crepe paper, because fibers from a cleaning cloth can cause malfunction.

Protective caps on threaded chambers are to be removed just before the assembly of the unit.

Flush hoses and pipes with gasoline or other cleaning agent and blow through with compressed air before mounting.

Bolting must be properly tightened. However, do not use brute force.

1.7. Safety machine accessories

The machine is equipped with safety accessories. It protects the operator from injuries and the machine before damage. The safety accessories are blocking accessories, emergency switches and covers.

Check once in a week the function of the safety accessories. If the safety accessories are functionless, you must stop work and repair or change the safety accessories.

Enhanced risk!

Do not come into or intervene in the cutting area. Otherwise, there is a danger of injury, cutting or squeezing.

1.7.1. Total Stop

TOTAL STOP button is used for emergency switching – off of the machine in a case of defect or health hazard. By pressing the **TOTAL STOP** button the supply of electrical power is interrupted.

If any faults or states of emergency appear, immediately press the TOTAL STOP button!

Release of pressed button is possible by twisting the upper part of the button.

The TOTAL STOP button is placed on the control panel of the machine.



1.7.2. Saw arm cover

If the cover is opened during operation, the limit switch is opened and the band saw is stopped. The band saw is not possible to start in set mode.



The band saw is stated to the operation, when the covers is closed! Limit switched on saw arm control if covers are open or not.

1.7.3. Saw band stretching and rupture inspection


This device checks the saw band stretching and causes immediate machine shut – down in the event the band ruptures.



The device contains limit switch. Check the stretching carefully and periodically – eventually adjust.

1.7.4. Band saw covers


These protective covers overlap the saw band in the areas from guiding cubes to the arm.



Never switch on the saw band driver if this cover is not mounted!


1.7.5. Brush cover

It covers the brush for saw blade.




Never switch on the saw band driver if this cover is not mounted!

1.8. Umístění štítku stroje /
Maschinenschild position /
Position of machine label



Machine label is placed on saw arm between pile and saw band drive.

1.9. Umístění bezpečnostních značek / Verteilung der Sicherheitszeichen / Position of safety symbols




PO:
Noste pevnou pracovní obuv
Tragen Sie Sicherheitsschuhe
Wear fixed protective shoes

CZ:
Přečtí návod k použití
Bedienungsanleitung lesen
Read the operating instructions

OBS:
Noste ochranné brýle a sluchátka
Tragen Sie eine Schutzbrille und
Gehörschutz
Wear protective goggles
and headphones



NSS
Nebezpečí stlačení svérákem
Pressungsgefahr
Crushing hazard by vice



NE
Nebezpečí úrazu
elektrickým proudem
Verletzungsgefahr vom
elektrischen Strom
Electrical hazard



HV
Hlavní vypínač
Hauptschalter
Main switch



NR:
Nebezpečí zachycení
Erfassungsgefahr
Tramping hazard







SP:
Směr pohybu
Bewegungsrichtung
Direction of motion



2. **Dokumentace stroje/ Dokumentation der Maschinen/ Machine documentation/**

2.1. Technická data / Technische Daten / Technical data

Hmotnost stroje / Maschinengewicht / Machine weight:				
• Hmotnost / Gewicht / Weight	1400 kg			
Rozměry stroje / Maschinengröße / Machine size :				
• Délka / Länge / Length	2350 mm			
• Šířka / Breite / Width	2450 mm			
• Výška / Höhe / Height	2100 mm			
Elektrické vybavení / Elektrische Ausrüstung / Electrical equipment:				
• Napájení / Versorgungsspannung / Supply voltage	~3 x 400 V (230 V), 50Hz, TN-C-S/TN-C			
• Příkon / Gesamtschlusswert / Total Input	5,2 kW			
• Max.jištění / Max. Vorschaltsicherung / Max. Fuse	16 A			
• Krytí / Schutzart / Protection	IP 54			
Akustický tlak / Schalldruckpegel / Acoustic pressure:				
• Individual 520.360 DGH	L _{Aeqv} =76,3 dB			
Pohon / Antrieb / Drive:				
• Typ / Typ / Type	BN112M4			
• Napájení / Versorgungsspannung / Supply voltage	~3 x 400V, 50Hz			
• Výkon / Leistung / Output	3 kW			
• Jmenovité otáčky / Motornenndrehzahl / Nominal speed	1440 min ⁻¹			
Hydraulické zařízení / Hydraulikeinrichtung / Hydraulic equipment:				
• Typ / Typ / Type	SSM-3/79+76+16-1/3-17/02400			
• Výkon / Leistung / Output	3 kW/8 MPa			
Chladicí zařízení / Kühlmiteleinrichtung / Cooling equipment:				
• Typ / Typ / Type	3-COA4-12			
• Výkon / Leistung / Output	0,05 kW			
• Obsah nádrže / Volumen vom Kühlmittel / Capacity	35 l			
Rozměr pásu / Sägebandedimension / Band size:				
4780×34×1,1 mm				
Řezná rychlost / Schnittgeschwindigkeit / Cutting speed:				
20–120 m/min.				
Řezné rozsahy / Schnittbereiche / Cutting size:				
				
0°	Ø360 mm	520×360 mm	360×520 mm	360×360 mm
45° R	Ø360 mm	360×325 mm	360×310 mm	350×350 mm
45° L	Ø360 mm	365×350 mm	360×320 mm	320×320 mm
60° R	Ø240 mm	240×310 mm	360×190 mm	240×240 mm
60° L	Ø255 mm	250×340 mm	360×200 mm	250×250 mm


Warning:

If the material detection device is installed on machine maximal workpiece height is 10 mm shorter.


Level of acoustic pressure:

Equivalent level of acoustic pressure A (noise) at operator position are $L_{Aeqv}=76,3$ dB. Mentioned values are levels of emission which doesn't have to represent safe levels. Factors which influence real level of acoustic pressure on machine operator are: working place characteristics, cut material, saw band. These factors have significantly influence on acoustic pressure.

2.2. Rozměrové schéma / Aufstellzeichnung / Installation diagram



2.3. Popis / Beschreibung / Description



2.4. Transportation and stocking

2.4.1. Conditions for transportation and stocking

Keep recommendations for the manufacturers for transportation and stocking! If the recommendations are not kept, damage can occur to the machine.

- Don't use a forklift truck for handling the machine, if you do not have license for it!
- Don't move under suspended loads! Fault in lifting device may cause serious injury.
- Keep a safe distance from the machine during the transport.
- Temperature of the air from -25°C to 55°C , for a *short term* (max. 24 hours) temperature of the air until 70°C
- Do not expose the machine to radiation (for example microwave radiation, ultraviolet radiation, laser radiation, x-ray radiation). Radiation can cause problems with the machine function and deteriorating condition of the isolation.
- Take measures, to prevent damage by dampness, by vibrations and by shakes.

2.4.2. Transport and stocking preparations

Close the vice and thoroughly oil all blank surfaces.

Lower the saw frame to the lowest position.

Make sure to empty the machine of all traces of the cooling agent.

Fasten all loose parts securely to the machine.

Pack and wrap the control desk securely to avoid damage during transport.

Fix the stickers stating the minimum approximate machine weight to at least five well visible places.



2.4.3. Transport and stocking

Handle the machine only with a hand pallet truck or a forklift truck! Always place the forks of the forklift from the side of the saw accordingly to the transport diagram.


- Make sure that the hand pallet truck or forklift truck have sufficient lifting capacity.
- Make sure that the van or the trailer had sufficient capacity
- The machine must be secured sufficiently during transportation so it won't roll over or fall off the vehicle.
- Fasten the pallet to the floor of the vehicle.
- Beware of damaging the machine during transportation.
- It is forbidden to handle the machine in any way different from that written in these operating instructions (for example lifting it by the saw arm); the machine could get damaged!
- Store the machine only under conditions mentioned in the manual to avoid damaging it.
- Place the forks of a fork lift truck according to these signs!



2.4.4. Transportní schéma / Transport schema / Transport scheme



Prostor pro lyžiny vozíku
Die Stelle für Greifen mit den Gabeln des Gabelstaplers
Place for forklift's skides



2.5. Activation

2.5.1. Machine working conditions

Keep the conditions of the manufacturer for machine operating! If recommendations are not kept, damage can occur to the machine.

The manufacturer warrants the correct function of the machine for these conditions:

- At temperature air from **10°C to 40°C**, the temperature average during 24 hours must **not exceed over 35°C**.
- At relative dampness of the air in the extend from 30% to 95% (not concentrate). Altitude lower than 1000 metres.
- Do not expose the machine to the radiation (for example microwave radiation, ultra-violet radiation, laser radiation, x-ray radiation). Radiation can cause problems with the machine function and deteriorating condition of the isolation.

Attention!

If the ambient temperature drops below 15 °C is required before operating the machine to have switch on hydraulic unit around 10 minutes and then made several motion few times (for example, in manual mode) by all hydraulic cylinders. The reason is to heat hydraulic oil to the operating temperature for proper function of the pressure switches (and choke).

2.6. Band saw unpacking and assembling

Remove the packing from the machine and unpack all parts.

Attention!

Switch off the main switch and lock it, before you start assembly! Otherwise, there is possibility of hazardous machine starting.

If the hydraulic unit is outside the machine (the machine only connected hoses and cables), it needs to be placed and mounted on a solid basis (floors, etc.). The mounting holes are used on the bottom (bases) of the tank.

2.6.1. Machine installing and levelling

Check the floor supporting capacity before machine installing. If the floor capacity does not agree with requirements, you must prepare the necessary base for the machine.

Minimal requirement:

machine weight – Individual 520.360 DGH – 1400 kg

+ weight of accessories

+ maximum weight of material

- The machine must be levelled at the horizontal position. All feet of the machine must touch with the floor after levelling
- The machine must be levelled by means of the calibrated spirit level. Spirit level is put on the vice area. Set the roller conveyors according to the spirit level.
- For machine levelling, take care that there is sufficient available space for operation, repair work, servicing of the machine and handling the material..
- The machine including appended parts and accessories must be visible from the place of operation.

2.6.2. First run of the power pack

Before the first run check:

- The direction of the Pump, while run the power pack for max. 2seconds.
- The cooling fan of the motor has to rotate in the same direction as the arrow on the top of the motor cowling indicates.
- In case of wrong rotational direction, the electrical phase in the connection box is to be changed. This check is required after every disconnection from the power source
- Wiring matches with electrical and hydraulic diagrams
- the electric motors (pump and cooler) are properly connected and have the prescribed rotation
- the hydraulic accumulator with nitrogen gas to the specified value
- aux. elements work right (thermometer, level gauge, heater)

First run (Attention – working pressure on securing valve is set by producer in accoring the hydraulic diagram):

- In the short intervals activate an electric pump
- check for leaks and noise
- Bleed the hydraulic circuit
- if possible, test the circuit function with minimum load
- test the electrical equipment
- during operation monitor measuring equipment, noise, height and temperature of oil in the tank
- During this time a careful bleeding off for the whole hydraulic system is necessary. In case there is no bleeder port, the power pack will bleed itself after a while via the air breather on the tank or the return line filter.
- After multiple start-up.

2.6.3. Einfüllung des Hydraulikbehälters

Füllen sie den Tank mit einem der Hydrauliköle, die in der Tabelle angezeigt sind. Es handelt sich um Hydrauliköle der Klasse HM und HV nach europäischen Spezifikationen CETOP RP 91H in Viskositätklassen ISO VG32.


Die Einfüllung des Aggregats hat über geeignete Filtervorrichtung mit Filterfeinheit von 20 µm oder besser zu erfolgen!

Sollte es zum Leckage vom Öl kommen, ist es der Verunreinigung der Wasserquellen zu vermeiden. Das verschüttete Öl kann mit einem geeigneten chemischen Mittel entfernt werden (Vapex), oder mit Sägemehl oder Sand bestreut. Lagern Sie dieses aufgesaugtes Material an einer dazu bestimmten Deponie ein.

Das Hydraulikaltöl ist es in Übereinstimmung mit dem Gesetz zu entsorgen.

Ölsorte	kinematische Viskosität ν mm ² /s in Abhängigkeit von der Temperatur					Gefrierpunkt
	0°C	20°C	40°C	60°C	80°C	°C
OH-HM 32	220	100	32	15	7	-40
OH-HV 32	180	67	32	17	11	-40

2.6.4. Verankerungsplan / Grounding plan



Kotvící materiál / Verankerungsmaterial / Grouding material

- 4x Hmoždina / Dübel / Plug – $\varnothing 18$ mm
- Vrtáno do hloubky / In die Tiefe gebohrt / Drilled to – 120 mm
- Šrouby / Schraube / Screws – 150xM16

Šrouby podložit deskami o min. rozměrech P10x100-100
 Die Schrauben mit Platten mit Minimaldimensionen P10x100-100 unterlegen
 Screw must be bottomed with plates (min. dimensions P10x100-100)

Požadavky na rovinnost podlahy / Anforderungen an die Bodenebenheit / Requirements for floor flatness

± 10 mm / 1 m

2.6.5. Electrical connection

Attention!

Only a qualified professional must carry out the servicing and repairs of the electric equipment! Take special care during work with the electrical equipment. High voltage accident can have fatal consequences! Always follow instructions for work safety.

Electrical parameters of the machine:

- Service voltage: $\sim 3 \times 400 \text{ V (230 V)}$, TN-C/TN-C-S, 50 Hz
- Total input 5,2 kW
- Max. fuse 16 A

Note:

Values of the cross section of the conductor and the rated current can be found in the regulations.

Before connecting the machine turn off the main power switch and ensure a dry area for the connection work.

Service voltage must agree with the line voltage! Cross section of the supply line must respond with the rated current for max. machine load.

Note:

A socket with fork can be used only for machines with the rated current less than 16 A and total input less than 3 kVA.

In case the machine is connected directly to the electrical network terminals, an extra main switch which can be locked in zero position must be added.

Attention!

In this case the extra switch on the electrical line becomes the primary switch and the main switch on the machine has only a secondary function!

2.6.6. .Check the direction of the saw band



After the machine has been successfully connected, briefly switch on the machine and put the driving engine of the band in the running position. The direction must be in accordance with the arrow direction on the saw band cover. In case the direction of the saw band does not match, two phases at the terminal strip must be switched.

2.6.7. Check machine connection into electrical network



Attention!

When you connect the machine to the electrical network secure a correct connection of all phases!
THE HYDRAULIC AGGREGATE ENGINE MUST NOT BE OPERATED IN REVERSED DIRECTION FOR MORE THEN 10 SECONDS!!!



2.6.8. Filling of the cooling system

Prepare the mixture of the water and the cooling liquid. Keep the concentration specified by manufacturer. Shift away the cover from the drainage hole. Fill the mixture of the water and the cooling liquid to the tank of the cooling system. Area of the tank for the cooling liquid is discovered from the chapter *Technical data*.

Let the drainage hole opened and with the sieve during operation, because it secures the right work of the cooling system. Filling the tank with the cooling liquid, take care that the liquid does not drip out of the tank and the tank does not overflowed.

Note:

If the machine is equipped with a Microniser, fill the Microniser with prescribed cooling liquid. This makes the Microniser ready for operation.

2.7. Check machine function

Check, if the machine or some parts of the machine were not damaged during transport.

Check, if covers are installed and functional. Check by means of the Tenzomat if the saw band is correctly stretched. If it is necessary, you can stretch the saw band according to chapter *Selection and replacement of the saw band*. Values of the saw band stretching are on the Tenzomat. Switch on the main switch and check the motors and systems (saw band drive, hydraulic pump, cooling pump, chips conveyor).

Open and close the main vice. Turn the saw frame of the band saw from one outer position to other outer position. Raise the saw frame to the top position and drop the saw frame to the lowest position.

Start the machine with the cooling pump and let it run without load until the cooling system will be filled with cooling liquid. As soon as the cooling liquid starts to escape from the nozzles of the cooling system, the cooling system is ready for the operation. Carry one cycle of cutting without material. Check, if the machine runs with no irregularities. If all machine functions are right, the machine is ready for operation..

2.7.1. Machine disposal after lifetime

Blown out all service fluids (cooling liquid, hydraulic oil) into designated reservoir.
 Dismantle machine into separate parts and dispose them in accordance with valid directives

2.8. Saw band

Refit the saw band cover only after you have installed and tightened the saw band.



2.8.1. Saw band size

4780x34x1,1 mm

2.8.2. Selection of the saw band tooth system

The manufacturers provide the saw bands with constant and variable tooth system. The important factor for selection of the tooth system is length of the cutting canal with respect to the size of the product

1. *Constant tooth system* – the saw band has parallel tooth pitch all over length. This way is suitable for cutting of solid material.

BOMAR recommended Variable tooth system for band saw.

2. *Variable tooth system* – tooth pitch is variable. Variable tooth system is used for profiled materials and bundle cutting. Variable tooth pitch lowers vibration of the saw band, increases service life of the saw band and quality of the cutting area.

In tables, there are advised type of the tooth system depending on sizes and form of the cutting material.

Footnotes:

Z₁Z₂ – teeth number on one inch S – tooth with zero angle of the teeth K – tooth with positive angle of the teeth

Examples of the tooth system marking:


32 S – number „32“ means 32 teeth on one inch (that means constant tooth system), letter „S“ marks teeth with zero angle of the tooth.

4–6 K – number „4–6“ means 4 till 6 teeth on one inch (that means variable tooth system); letter „K“ marks teeth with positive angle of the teeth.

2.8.3. Saw band running-in






Running-in: Cut the material with the frame lowering reduced to 50% only. When vibrations occur increase or decrease the band speed.

When cutting small pieces run the band until approximately 300 cm² of material has been cut. When cutting large pieces run the band for 15 minutes approximately. When the band has been run, increase the lowering-speed to normal speed. The running in of the saw band avoids micro-breaks on the cutting edges of new saw band ensuing from first excessive stress. This would decrease service life substantially. The optimal running in of the saw band produces ideal rounded cutting edges and therefore the conditions for an optimal service life.







Note: Run regrinding saw bands too.

2.8.4. Tables for teeth selection

SHAPED MATERIAL ($D_p, S = \text{mm}$)						
						
Note: Table shows tooth system selection for cutting one piece of the profile. For cutting of more pieces of the profiles (bundle), you must think of the size of the wall as double size of the wall of one profile (that means, size „S“ equates to 2xS). In table, there are tooth systems constant and variable.						
Size of the wall S [mm]	Tooth system (Z_p, Z) Outer diameter of the profile D_p [mm]					
	20	40	60	80	100	120
2	32 S	24 S	18 S	18 S	14 S	14 S
3	24 S	18 S	14 S	14 S	10–14 S	10–14 S
4	24 S	14 S	10–14 S	10–14 S	8–12 S	8–12 S
5	18 S	10–14 S	10–14 S	8–12 S	6–10 S	6–10 S
6	18 S	10–14 S	8–12 S	8–12 S	6–10 S	6–10 S
8	14 S	8–12 S	6–10 S	6–10 S	5–8 S	5–8 S
10	-	6–10 S	6–10 S	5–8 S	5–8 S	5–8 S
12	-	6–10 S	5–8 S	5–8 S	4–6 K	4–6 K
15	-	5–8 S	5–8 S	4–6 K	4–6 K	4–6 K
20	-	-	4–6 K	4–6 K	4–6 K	3–4 K
30	-	-	-	3–4 K	3–4 K	3–4 K
50	-	-	-	-	-	3–4 K

Size of the wall S [mm]	Tooth system (Z_p, Z) Outer diameter of the profile D_p [mm]					
	150	200	300	500	750	1000
2	10–14 S	10–14 S	8–12 S	6–10 S	5–8 S	5–8 S
3	8–12 S	8–12 S	6–10 S	5–8 S	4–6 K	4–6 K
4	6–10 S	6–10 S	5–8 S	4–6 K	4–6 K	4–6 K
5	6–10 S	5–8 S	4–6 K	4–6 K	4–6 K	3–4 K
6	5–8 S	5–8 S	4–6 K	4–6 K	3–4 K	3–4 K
8	5–8 S	4–6 K	4–6 K	3–4 K	3–4 K	3–4 K
10	4–6 K	4–6 K	4–6 K	3–4 K	3–4 K	2–3 K
12	4–6 K	4–6 K	3–4 K	3–4 K	2–3 K	2–3 K
15	4–6 K	3–4 K	3–4 K	2–3 K	2–3 K	2–3 K
20	3–4 K	3–4 K	2–3 K	2–3 K	2–3 K	2–3 K
30	3–4 K	2–3 K	2–3 K	2–3 K	1,4–2 K	1,4–2 K
50	2–3 K	2–3 K	2–3 K	1,4–2 K	1,4–2 K	1,4–2 K
75	-	2–3 K	1,4–2 K	1,4–2 K	1,4–2 K	0,75–1,25 K
100	-	-	1,4–2 K	0,75–1,25 K	0,75–1,25 K	0,75–1,25 K
150	-	-	-	0,75–1,25 K	0,75–1,25 K	0,75–1,25 K
200	-	-	-	0,75–1,25 K	0,75–1,25 K	0,75–1,25 K

SOLID MATERIAL ($D = \text{mm}$)						
						
Constant tooth system			Variable tooth system			
length of the cut D		tooth system (Z_p, Z)	length of the cut D		tooth system (Z_p, Z)	
to 3 mm		32	to 30 mm		10–14	
to 6 mm		24	20–50 mm		8–12	
to 10 mm		18	25–60 mm		6–10	
to 15 mm		14	35–80 mm		5–8	
15–30 mm		10	50–100 mm		4–6	
30–50 mm		8	70–120 mm		4–5	
50–80 mm		6	80–150 mm		3–4	
80–120 mm		4	120–350 mm		2–3	
120–200 mm		3	250–600 mm		1,4–2	
200–400 mm		2	500–3000 mm		0,75–1,25	
300–800 mm		1,25				
700–3000 mm		0,75				

In spite of the proposals above, consider your supplier's recommendations and ask him for professional advice even though the manufacturers will often recommend their own saw bands.

3. Ovládání stroje/ Bedienung der Maschine/ Machine control

3.1. Starting the band saw

- » 1. Switch on the main switch of the band saw. The main switch is situated on the side of the switchboard.




2. After a few initialization screens the screen appears with information that the safety circuit isn't switched on.







3. Switch on the safety circuit of the band saw **Safety circuit** (button **2**) on control panel of the band saw.



3.2. Control panel



3.2.1. Control panel description

1	LCD Display Onto display are described all running processes, control with functional buttons F1-F4
2	Control buttons / numeric keypad
	GH version – no function DGH version – vice movement right/left
	Clamp / release vice clamp
	Clamp / release vice In manual cycle pressing and holding the button allows you to release pressure or clamping vise.
	Cooling system selection Cooling with Microniser (optional accessories) Cooling with water cooling pump runs even when the saw band drive is switched off.
	Movement of the arm Pressing and holding a button or trigger arm lifts the lifting hydraulic cylinder. When lifting the arm using the arm can be lifted in its entirety lifting cylinder. On the down can be activated by simultaneously pressing the rapid move functional button F1.
	No function
	Turn on / off the band drive In manual mode the button is displayed "I" switched band drive, the button with the symbol "0" switch off
	Turn on / off the hydraulic circuit Button with the symbol "I" turns the hydraulic circuit, the button with the symbol "0" disables the hydraulic circuit. The hydraulic circuit is automatically switched on when needed.
3	Safety circuit Switch on the safety circuit by pressing button.
4	Button START - Switch on the semi-automatic cycle After pressing the button will start the cutting cycle

5	Selecting a mode machines  for servicing and settings  manual mode  semi-automatic mode
	Note: The functions performed in both manual and semi-automatic mode are the same, but only in semi-automatic cycle it is possible to use the START / STOP (ie start / off cycle)
6	Button STOP - Switch off on the semi-automatic cycle After pressing the button will turn off the interruption or of cutting cycle
7	TOTAL – STOP button In emergency causes the machine must be immediately switched off.
8	Frequency convertor Turn to change the speed of the saw band in the range of 20-120 m / min
9	Cutting pressure manometer Pointer to cut pressure adjustment
10	Cutting pressure regulation Adjust the arm pressure to the cut.
	Notice: If you keep closing the throttle valve too tightly, the valve seat may wear off which causes its leakage. Therefore, close the valve always gently.
11	Governing valve for adjust the speed of the arm sinking to the cut Adjust the speed of the arm sinking to the cut by governing valve.
	Notice: If you keep closing the throttle valve too tightly, the valve seat may wear off which causes its leakage. Therefore, close the valve always gently.

3.3. Machine referencing

After switching on, the machine must always be referenced!

Unless referencing has been done, semiautomatic cycle cannot be started and it is impossible to turn the arm and move the table in the manual mode.

Movements necessary to release the band from cut and material from the vice (vertical arm travel, vice jaws movement and bundler jaws movement) can be controlled in the manual mode even without referencing.

Provedení referenční sekvence:

1. Choose the position  on the mode selector.



Na displeji se zobrazí následující obrazovka:




2. **Push and hold the START button** (position 4 on the control panel), thus the machine referencing is started.

Referencing process:

Referencing is setting of the machine in the basic reference position. Referencing is always required after switching on the main switch; the movement sequence during referencing is always the same. If a referencing step is not observed, the machine stops and does not continue with referencing until the previous step has been fulfilled.


Referencing of the Topline machines is executed in a sequence of 4 (5) successive steps. Within each step, one specific movable unit of the machine is set to the basic position and this setting is the start-up condition of referencing movement of the next unit. Setting of the last unit to the basic position is the condition of the end of referencing.


Achievement of basic position of the pertinent unit is detected by the limit switch or inductive switch; at the same time, fulfilment of the referencing condition is indicated by the pertinent cross on the control panel display.





If four crosses are lit (or five crosses - for machines equipped with a bundler), successful end of referencing is indicated.

If the referencing sequence is interrupted before its end, check the pertinent switch/sensor of the basic position of the unit before the step of which the sequence stopped, and its counterpart. If necessary, replace/adjust the damaged part according to the chapter "Adjustment and maintenance".

Referencing process	Display indication	Referencing condition	Switch location
Step 1	X	Arm in upper position	Limit switch of upper arm position 
Step 2	XX	Bundler fully open (optional equipment)	Inductive sensor of full opening of the bundlere 

Referencing process	Display indication	Referencing condition	Switch location
Step 3	XXX	Vice fully open	Limit switch of full opening of the vice 
Step 4	XXXX	Table position on the left (from operator's perspective) Caution! This referencing movement is only executed by the Topline DGH version with automatic swivelling of the angle!	Inductive sensor of the table located on the left 

Referencing process	Display indication	Referencing condition	Switch location
Step 5	XXXXX	Arm position at angle of 0° Note: During referencing, the arm starts moving in slow, smooth move to the right (from operator's perspective) and is rotating until the reference limit switch is closed. After closing, the arm quickly returns to the preset angle 0° - by this last sequence, referencing is finished, the machine has been REFERENCED. Caution! This referencing movement is only executed by the Topline DGH version with automatic angle swivelling!!	 Referencing limit switch of the arm position  ELGO sensor for angle measurement 

3. At the end of successful referencing, a screen appears with the message, that referencing has been completed



4. Release the **START** button.

Information on referencing completion disappears and the machine is ready to start the semiautomatic cycle.



3.4. Control of the machine Topline 510.350 DGH

3.4.1. Semi-automatic cycle

1. Lift the saw arm to the top position by pressing button .
2. Open the vice by pressing button .
3. Clamp material to the vice by pressing button .
4. Lower the frame about **10 mm above the material** by button .

Attention!

Do not move the saw frame to the material, when the saw band driving is not running! Do not move the saw frame to the material with accelerated motion! The saw band can be damaged!

5. Select the max. height of the arm with limit switch.

You can clear the register of the performed cycles by button  and stop on 5 seconds.

6. Press button **START** (position **4**) of semi-automatic cycle.

Set the saw band speed according to the kind of the cutting material.

Set the speed of the arm sinking by adjust governing valve (position **10**).

Attention!

Press button „5“ (STOP of semi-automatic cycle). In risk of injury or damage of the band saw, press the emergency button TOTAL STOP „10“!

7. The band saw clamps the material to the vice and it makes the cut.

8. Open the vice. If the vice is not opened, you can open it by button . Remove the blank ((cut off a piece of material).
9. You can repeat whole process.

3.5. Control of the machine Topline 510.350 DGH with automatic swivel of the arm angle

3.5.1. Manual control

- 1 Choose the position  on the mode selector.

The screen appears for control of the machine in the manual mode.



The screen shows information on the current state of the machine

In this mode, you can control the individual machine movements with the buttons on the machine control panel.

3.5.2. Semiautomatic mode

- 1 Choose the position  on the mode selector.



- 2 Before starting the semiautomatic cycle, you must set the **swivel angle of the arm**:

- a) Push the **F2** button to set the angle.



- b) Enter the angle value by means of the keyboard.



- c) By means of the F1 button, change the sign (+/-).



- d) Confirm by pushing the F4 button (OK)



- e) The **Press START** prompt appears on then screen and the START button starts flashing



Note::

F1 <ESC> - return to previous screen

- f) Push the **START** button

Hold the **START** button until the saw sets at the required angle and a screen appears on the display with the information that the angle has been set



- 3 Then set the **arm height**:

- a) Set the arm height by means of  and 

Caution!

Do not lower the saw arm to the material unless the saw band drive is on! Do not lower the saw arm to the material with fast feed! The saw band might be damaged!

- b) Save the value by pushing the function button **F1**.



- 4 Push the function button **F4** to enter the **material width** (the final cut depth will be calculated).



- a) Enter the material width by means of the keyboard



- b) Confirm by pushing the F4 button (OK).



- 5 Push the START button to start the semiautomatic cycle.



3.5.3. Cycle breaking


- » • **STOP button**
Semi-automatic cycle is interrupted by pressing button **STOP** (position **6**) of the semi-automatic cycle.
The arm is lifted to the top position and the saw band drive is stopped..
By pressing button **START** (position **4**) of the semi-automatic cycle, you can start the cycle.
- **TOTAL STOP button**
In case of the risk, press button **TOTAL STOP** (position **7**).
After pressing **TOTAL STOP** button, saw band drive is immediately broken and the arm sinking is stopped.
- **Reactivation**
 1. Turn button **TOTAL STOP** according to the arrows (on the button).
 2. Switch on the **Safety circuit** by button (position **3**).
 3. By pressing button **START** (position **4**) of the semi-automatic cycle, you can start the cycle. The arm is lifted to the top position and the saw band starts the cycle.

3.6. Machine setup

Machine setup mode is activated by switch on control panel. Switch must be in "0" position.



After switching into position "0" is displayed on LCD this screen.




Note:


Selection „Service of blade“ – without function

3.6.1. SERVICE

After pressing the **F1** functional key can be set servis parameters that are password protected (947).



Control and movement in **SERVIS** can be set using the function keys **F1 - F4**.

On display	Description
	Deviation of reference - Reference switch deviation from the zero angle of the saw F1 <ESC> go back, F4 next menu screen, F2 <OK> - enter value
	Number of pulses per degree - Number of pulses of the ELGO band per 1 degree F1 go back, F4 next menu screen, F2 <OK> - enter value
	Vice clamping time - Watch vice clamping time in ms. F1 go back, F4 next menu screen, F2 <OK> - enter value



Blade speed correction

- Constant for calculation of the band speed value displayed from the analog input.
- **F1** go back, **F4** next menu screen, **F2** <OK> - enter value




Max. arm position

- Arm height after machine referencing
- **F1** go back, **F4** next menu screen, **F2** <OK> - enter value




- **F1** go back, **F4** next menu screen,



- **F1** go back, **F4** next menu screen,


3.6.2. SETUP

After pressing the **F4** functional key can be set setup parameters that are not password protected.




Control and movement in SETUP can be set using the function keys **F1 - F4**.

On display	Description
	Finish of cycle - At the top – arm after cut starts above the material and cutting cycle ends - At the bottom – arm after cut remains in the lower position, the above material does not exit F1 <ESC> go back, F4 next menu screen, F2 – change of selection
	Turn off motor after cut - Up position – saw arm move up after cut and then turn off drive of saw blade. - Down position – drive of saw band turn off immediately after cut. F1 <ESC> go back, F4 next menu screen, F2 – change of selection
	Upper vice - Allows to able / disable the upper vice in the cutting process F1 <ESC> go back, F4 next menu screen, F2 – change of selection
	Vice opening time - Watch vice opening time in ms. F1 go back, F4 next menu screen, F2 <OK> - enter value

	Upper vice opening time • Watch upper vice opening time in ms. • F1 go back, F4 next menu screen, F2 <OK> - enter value
	Switch off hydraulic • Setting the hydraulic unit off when idle machines • F1 go back, F4 next menu screen, F2 <OK> - enter value
	Language • Choose menu language • F1 <ESC> go back, F4 next menu screen, F2 – change of selection

Pushing F4 on the last screen – return to the home screen for setting the machine and service parameters:



3.6.3. Machine error messages

Error	Information
SAFETY BUTTON is OFF F1 F2 F3 F4	Safety button (pos. 2 on kontrol panel) is not ON. Press F4 to confirm error.
TOTALSTOP pressed F1 F2 F3 F4	Total Stop button is active. Turn button TOTAL STOP according to the arrows. Press F4 to confirm error.
Blade tension faulty F1 F2 F3 F4	Saw blade in properly tensioned. Press F4 to confirm error.
Faulty motor protec. F1 F2 F3 F4	Engine temperature protection is active. Do not overload saw! Press F4 to confirm error.

3.7. Band saw adjusting


3.7.1. Angular cut setting

The machine enables angular cuts from 45° to -60°. The cut angle can be set fluently from **0° to 60°** on the left side and from **0° to 45°** on the right side.

1. Release securing lever of the console.



2. Swivel the frame to the desired angle by pulling the saw arm. Angle is shown on scale (see arrow)



3. After cutting angle setup tighten securing lever.

Attention!

*Moving parts of the vice must be moved when saw arm has zero angle of rotation and closed vice jaws.
Moving vice jaw of vice must be in endmost position otherwise there is a danger of collision saw arm with vice.*

3.7.2. Laserliner – optional accessory

The device is used to ascertain exact position of the material cut before cutting.

The cut is indicated by the laser beam projected on the surface of the prepared material..



The switch for Laserliner is located on the control board.



3.7.3. Saw frame lift stop setting – just for Topline 510.350 DGH

If you want to shorten the time of operations in automatic cycle, you have to adjust the height of the saw arm according to the height of the cutting material.



Notice:

Arm Position is monitored by a limit switch. If the limit switch lever hits the bar and goes, then you can not run a semi-automatic cycle.

1. Height adjustment is sensed by a limit switch

2. Press button  and lift the saw arm to the upper position.

3. Insert a material into the vice. Carefully lower the saw arm button  to the material.

4. Stop the saw arm 10mm above the material.
5. The lift stop setting is sensed by the limit switch

Set the stop just above arm height sensor - slide stop turning the locking knob close to the limit switch


3.7.4. Adjusting band guides

If you want to achieve a smooth and precise cut, it is helpful to position the guide cube as close as possible to the material.



1. Press button **STOP** (pozice **6**) to switch off the hydraulics and stop on 2 second.
2. Release the stopping lever of the listel (see picture).
3. Move the left part of the guide apparatus so that the left guide cube edge is as close to the cut material as possible.
4. Tighten the lever of the gib and check the guide cube setting for possible collision with binding table or vice jaw.

3.7.5. Cutting speed adjusting



Speed of the saw band is possible change from **20 to 120 m/min**. You can effect to adjusting speed of the saw band following.

Use the frequency convertor by button **8** (position on control panel) to adjust requested speed of the saw band. You can see the speed on display. Band speed is displayed on the screen **1** (position on control panel) during one semi-automatic cycle.

3.7.6. Adjustment of pressure to the cut

The band saw **Individual 520.360 DGH** is equipped with cutting pressure regulation on the both guiding cubes.

Pressure adjusting is performed with governing valve **9** (position on control panel).



Lower pressure to the cut – turn the wheel against the clock's direction.

Higher pressure to the cut – turn the wheel to the clock's direction.

3.7.7. Speed adjustment of the arm lowering

Set the speed of the arm lowering to the cut by control valve for Cutting pressure regulation **10** (position on control panel).



- Set the lower speed of the arm lowering to the cut by turning the switch clockwise.
- Set the higher speed of the arm lowering to the cut by turning the switch anti-clockwise.

Notice:

If you keep closing the throttle valve too tightly, the valve seat may wear off which causes its leakage. Therefore, close the valve always gently.

3.7.8. Brush setting

The brush influence the cutting power, lifetime of the saw band, circular wheels, hardmetal guides and precision of the cutting. Replace the brush each shift.


Check the brush adjustment every shift.

1. Dismantle the brush cover.



2. Set the brush position to the saw band by rotating the adjusting screw (see the arrow).


The brush must touch the saw band toothing.



Caution!

The brush must not reach the bottom of the saw toothing!

3. If the brush does not rotate correctly (the brush drive wheel is slipping on the drive wheel of the saw band), use the screws to push (see the arrows) the brush drive wheel to the saw band drive wheel.



Attention!

Do not overtighten the screws so that the brush drive wheel is not damaged or service life of the band drive wheel bearings reduced!

3.7.9. Halogen lighting of working area (optional accessory)


Light the working area of the machine with natural light and helps to facilitate cutting with a band saw.

Proper lighting in your work area greatly enhances ergonomics machines.



Thanks flexible arm halogen light can accurately adjust to the desired location.

Turn on and off light switch is made directly to the halogen light.



Design lighting unit meets IP54 - Protection against water jets.

Technical data:

Supply voltage	230 V
Lenght flexible arm	300 mm
average	Ø 5,5 mm
lenght	80 mm

3.8. Material insertion

- Never walk under a suspended load!
- Never climb onto the gravity-roller conveyor!
- Do not hold the material for clamping material to the vice! The vice can cause injury!

3.8.1. Handling agent selection


- Use the strong handling agents to lift and transfer the material!
- Handle with the material only with the lift truck or use the suspension strands and the crane!
- Do not use the lift truck or crane in case that you do not have the license to handle with it!

3.8.2. Insertion

Insert material to the vice and ensure that the material cannot move in the vice or fall from the vice after the clamping. If you cut long pieces of the material (for example rod, tube), you must use the roller conveyors for material shifting to the band saw. Contact Bomar for more information about roller conveyors

Make sure the conveyor is long enough and the material cannot tip off the conveyor.

Be especially careful with round materials that it always stays on two vertical rollers and that it cannot fall off the conveyor!



3.8.3. Bundle material cutting




If you want to cut the material in the bundle, there are suggestions for the positioning of bundles

Round material bundle: Take care especially with round material that the bars are put according to the picture. If the bars are put differently, you may have problems with movement.

Always weld the material at the rear end of the bundle to secure it from moving.

Before welding always, switch the machine off at the main switch! The magnetic fields, which often occur during welding, may damage the controls!

Square material bundle:



Attention:

Not all material shapes are suitable for bundle cuts. Keep the recommendation of your supplier of the saw bands for material insertion to the bundle.

4. Údržba stroje/ Wartung/ Machine service

4.1. Saw band dismantling

When dismantling the saw band, take care not to damage the limit switch of the saw band tightening!

1. Lift the saw arm to maximum position.



2. Switch off the machine and open the front cover of the saw band.




3. Dismantle the yellow protective covers of the band. Covers are fastened by screws



4. Turn by stretching star to the left side, release saw band stretching and pull down the saw band from the wheels.



5. Pull up the saw band from the guiding cubes.



6. To facilitate removal of the saw band from the guide cubes, tighten the adjusting screws of the hard metal guides on the guide cubes to release the saw band from the hard metal guides.
7. Prior to installation of the saw band, clean all track wheels, guide cubes and inner side of the arm thoroughly of all traces of chips and dirt. Keep in mind the teeth direction when installing the saw band.

4.2. Saw band installation

When installation of the saw band, take care not to damage the limit switch of the saw band tightening

1. Lift the saw arm to maximum position.



2. Switch off the machine and open the front cover of the saw band.



3. Insert new saw band in the guide cubes. Make sure the saw band runs between both guide rollers and it is pushed all the way to the top.



4. Put the saw band on both guide wheels. Make sure that the saw band ridge fits tightly to the wheel rim. Then push the saw band as far back as possible.



8.

5. Stretch the saw band by means of the screw, that the band did not falls from wheels. Now you can remove the plastic cover from the saw band teeth.



9.

6. Mount the yellow protective guards of the band. The guard arrow must correspond to the direction of the band arrow. If not, turn it.



10.

7. Close the front cover of the saw arm..
8. Adjust the hard metal guides – for the procedure, see the chapter on adjustment of the hard metal guides on the machine.

4.3. Saw band stretching and inspection

Right saw band stretching is one of the most important criteria's, which influents accuracy and saw band service life. Stretch the saw bands according to the selected saw band and the band saw. Keep the recommendation of your manufacturer.

Pilový pás Sägeband Saw band	Napětí pilového pásu Sägebandspannung Blade tension	Napětí pilového pásu PSI (pro Tenzomat) Sägebandspannung PSI (für Tenzomat) Blade tension PSI (for Tenzomat)
20 x 0,9 mm	160 N.mm ⁻²	23 500
27 x 0,9 mm	180 N.mm ⁻²	26 500
34 x 1,1 mm	210 N.mm ⁻²	30 500
41 x 1,3 mm	240 N.mm ⁻²	35 000
54 x 1,3 mm	240 N.mm ⁻²	35 000
54 x 1,6 mm	280 N.mm ⁻²	40 600
67 x 1,6 mm	290 N.mm ⁻²	42 000
80 x 1,6 mm	300 N.mm ⁻²	43 500

1. After mounting, tighten the saw band slightly to that it cannot fall from the wheels.
2. Mount Tenzomat on the saw band and lock it with screws.



3. Tighten the saw band until it is tightened to the required value.
11. If a hydraulic pressure gauge is installed for measuring of the band tightening (optimal accessory), switch on the hydraulic unit after mounting the saw band and check the pressure of the saw band tightening on the pressure gauge.
12. If the saw band is tightened correctly, the pressure gauge pointer is on the green arrow in the scale.



4.4. Adjusting of the saw band run

Saw band run on the stretching wheel must be regularly inspected. The inspection has to follow every saw band replacement.

4.4.1. Saw band run inspection

If the run is not correct, the following problems may occur:

- **The saw band falls off the wheel** – the saw band and protective cover can be damaged.
- **The saw band runs on the wheel rim** – The saw band and wheel rim can be damaged




1. Start and stop saw band drive.
2. Stop the main switch!
3. Open rear cover of the saw frame.



4. Check saw band placing on the wheels.
 - If the distance of the rear part of the saw band from wheel rim is **1 mm**, setting is right.
 - If the distance is bigger than **1 mm**, or the saw band runs on the wheel rim, saw band run must be set.
5. When the check is finished install and close all covers.

4.4.2. Saw band run setting



Saw band run is set with screw (arrow) in the stretching cube on the saw arm. Right distance rear part of the saw band from wheel rim is **1 – 3 mm**.

Turn with the screw to the right, the saw band is closer to the stretching wheel rim.

Turn with the screw to the left, the saw band is far from the stretching wheel rim

Check saw band run adjustment again.

4.5. Saw frame lower position stop adjustment

The lower stop limits the lowest position of the saw frame. This stop has to be checked at least once a month. If the lower stop is adjusted incorrectly, the loading surface of the table can be cut too deeply or the material will not be cut through completely.



1. Raise the saw frame to the upper position
2. Release the nut of the adjusting screw and adjust the stop
3. Fasten the adjusting screw with the nut again
4. Set the limit switch of the lower arm position


4.6. Check and adjustment of switches and sensors

Warning!

All sensors, particularly those effecting the reference function, MUST regularly be checked, kept clean, or adjusted. Damage to these sensors, their incorrect position or contamination may result in MALFUNCTION of the machine!

4.6.1. Setting of the limit switch monitoring the band tightening


It is necessary to check the setting of the limit switch for band tightening monitoring at every band exchange. If the limit switch is not adjusted correctly, the band is tightened too little or too much.



1. Dismount the protective cover.
2. Tighten the saw band by means of TENZOMAT to the optimum value (see table on Tenzomat).
 - If the drive motor is on, yet the band is not running, turn the tightening screw clockwise with a spanner until the motor starts running.
 - If the drive motor can be started, turn the tightening screw counter-clockwise until the motor stops; then again shortly clockwise until the motor starts running.
3. Mount the protective cover.

4.6.2. Check of adjustment of limit switches of the upper and lower position of the arm

Adjustment of limit switches of the upper and lower arm position can be done with adjusting screws located on the limit switch holders.



1. Limit switch of the arm lower position

The limit switch of the lower arm position defines the arm stop in the lower position. If the switch is not adjusted correctly, the table may be cut through too deeply or the material cutting will not be finished.


If the lower arm stop has been adjusted, the limit switch must be set again.

Setting check

Lower the arm to the bottom position. If the arm rests on the lower stop and the limit switch has responded, the setting is all right. Otherwise set the switch.




The counterpart of the limit switch is the lower inclined plane of the stop plate




2. Limit switch of the upper arm position

The limit switch of the upper arm position has two functions - it defines the arm stop at the upper position and also defines the arm position at referencing.




The counterpart of the limit switch is the upper inclined plane of the stop plate.




4.6.3. Check of setting of the inductive sensor of the bundler opening


The inductive sensor of the bundler opening has two functions – it defines the position of full opening of the bundler movable jaw as well as position of the bundler during referencing




The counterpart of the inductive sensor is the upper surface of the bundler jaw.



To adjust the inductive sensor, carefully loosen/adjust the sensor and tighten the locking nuts on the threaded sensor stop. For faultless function of the sensor, you must set the gap between the sensor/jaw up to 1 mm.




Closing of the sensor (presence of the bundler jaws) is indicated by lighting of the pilot light on the sensor body.



4.6.4. Check and adjustment of the vice opening limit switch


The limit switch of the vice opening has two functions - it defines full opening of the movable jaw of the vice and also defines the movable jaw position at referencing.




The counterpart of the limit switch is the bar stop located on the moving jaw of the vice.



The position of the limit switch of full opening of the vice movable jaw towards the bar stop is adjusted by the setting screws located on the limit switch holder.



To adjust the bar stop, loosen the locking nut / adjust the stop / tighten the nut.




4.6.5. Check and adjustment of the table position inductive sensors

The right inductive sensor of the table position defines the table position on the right (from operator's perspective). To this position, the table is automatically moved if negative angles are divided.




The left inductive sensor of the table position has two functions – it defines the table position on the left (from operator's perspective); to this position, the table is automatically moved if positive angles are divided, and it also defines the table position during referencing.






The counterpart of the inductive sensors of the table position is the opposite surfaces of the stop bar, located in the central holder



The adjustment procedure of the inductive sensors is analogous to "Adjustment of the inductive sensor of the bundler opening".

These covers protect magnetic ends of the switches against impurities, particularly against collection of metal swarf. Removal of the covers may result in malfunction of the switches!



4.6.6. Check of switches and sensors of the arm rotation

The arm rotation is checked by the following sensors and switches:

1. **Limit switch of the arm extreme position during rotation at a negative angle** (for Topline DGH without automatic angle swivel and for Topline 510.350 DGH with automatic angle swivel)
2. **Limit switch of the arm extreme position during rotation at a positive angle** (for Topline DGH without automatic angle swivel and for Topline 510.350 DGH with automatic angle swivel)
3. **Referencing limit switch of the arm position** (only for Topline 510.350 DGH with automatic angle swivel)
4. **Sensor for position measurement during arm rotation** (only for Topline 510.350 DGH with automatic angle swivel)

The limit switch of the extreme arm position during rotation at a positive angle (for both types of Topline DGH), and also the referencing limit switch of the arm position and position measurement sensor during the arm rotation (for Topline 510.350 DGH with automatic angle swivel) are located on the slewing bracket under the cover.



To check/adjust the switches, remove 4 attachment screws of the cover.




To gain access to the extreme screw on the upper cover surface, swivel the arm in the manual mode to the position in which the screw can be dismantled.




1. **Limit switch of the extreme arm position during rotation at a negative angle**

Limit switch of the extreme arm position during rotation at a negative angle (see the arrow) is used to stop the arm during rotation at the extreme angle of **-60°**.




The counterpart of the arm extreme position limit switch at a negative angle is the stop plate located on the guide plate.




2. Limit switch of the extreme arm position during rotation at a positive angle

Limit switch of the extreme arm position during rotation at a negative angle (see the arrow) is used to stop the arm during rotation at the extreme angle of $+45^\circ$.




The counterpart of the arm extreme position limit switch at a positive angle is the stop plate located on the guide plate.




3. Reference limit switch of the arm position (only for Topline DGH with automatic angle swivel)

The reference limit switch of the arm position defines the arm position during referencing – after referencing starts, the arm is slowly and smoothly moving towards this switch; after closing, the arm quickly moves back to the initial/specified position.




The counterpart of the reference limit switch of the arm position is the stop plate.



The stop cannot be adjusted. In the case of its malfunction, replace it. If the switch is really damaged and must be replaced, it is NECESSARY to check or readjust correct arm positioning to the initial/specified position – CONTACT THE MANUFACTURER!

4. Sensor for position measurement during the arm rotation (only for Topline DGH with automatic angle swivel)


ELGO sensor for angle measurement – measuring sensor by means of which the rotation is set to the given angle. The sensor detects values against a magnetic tape located along the entire track of the bend measured. IT IS NECESSARY to keep this mechanism clean/undamaged, otherwise there is a risk of wrong positioning of the arm!



In the case of damage, CONTACT THE MANUFACTURER!

4.7. Check of the inductive switch to control the thrust to cut

The inductive switch for control of thrust to cut is used to control the thrust to cut depending on the current band deflection.



The counterpart of the inductive switch for control of thrust to cut is the opposite area of the guide cube.

Regularly check the state of the switch and counterpart; the recommended interval is once a month.

If problems with the thrust-to-cut control occur, check the state of this switch.


If the switch is adjusted incorrectly, it is necessary to readjust the device for thrust-to-cut control – see chapter “Adjustment of the device for control of thrust to cut”.

If the switch is damaged, contact a special service.

4.8. Adjustment of the device for control of thrust to cut

If the holder with the inductive sensor for control of thrust to cut has been dismantled, the thrust to cut control must be readjusted in the following way:

1. Adjust the distance between the inductive switch and the opposite cube area to 2 mm



4.9. Cooling agents and chips disposal

The quality of the cooling agent will deteriorate due to:	If the solution is too weak:	If the solution is too strong:
• use of contaminated water • impurity • outside oil contamination (hydraulics, gears) • high operating temperatures • lack of air circulation • wrong concentration	• corrosion protection is diminished • lubrication decreases • microbial attack is more likely	• the cooling ability is decreased • foam behaviour increases • emulsions stability deteriorates • sticky residue develops

4.9.1. Coolant device inspection

The state of the cooling agent has significant influence on the cutting quality and on the operational life of the machine. Lifetime of the cooling liquid is 1 year, after this time we recommend change the cooling liquid. This time is dependent on the degree of pollution cooling liquid (especially with oils) and on the other factors.

Check level of the cooling liquid and function of the pump periodically!

Note:

If the state of the cooling liquid is not satisfactory, the cooling liquid must be changed.

Check the state of the cooling agent according to the following table:

Testing	Interval	Method	Condition	Precaution
Liquid level	daily	visually	too low	after concentration check, refill with water or emulsion
Concentration	daily	refractometer densimeter	too high too low	refill water refill base emulsion
Smell	daily	by sense of smell	unpleasant smell	good ventilation, add biocides or renew coolant
Contamination	daily	by sense of smell	visible oil leaks, sludge fungi	surface cleaning, fix leaks, add biocides or fungicides, or coolant renewal after added system cleanser*
Corrosion-protection	when necessary	visually chip test Herbert-test	insufficient corrosion protection	test stability, if necessary – increase concentration or pH value
Stability	when necessary	refractometer	oiling	add concentrate, enquiries to supplier
Foam reaction	when necessary	shaking test	too much foam, foam disperses too slowly	avoid aeration, increase water hardness, ix with defoamer

* According to manufacturers' instructions

4.9.2. Mikroniser(box) – mist lubrication

The placement of a Microniser at the machine is pursuant to this photo




Next photos are for illustrative purposes only.

Microniser is a device used to create a lubricating oil mist in precise doses of oil and air mixture, which is then applied directly to the saw band.




.Microniser setting:


1. For proper function of the Microniser pressured air (in the range of 0.5 to 0.5 MPa (5-6 bar)) must supplied from the pneumatic system (dry, clean, free of particles) see - arrow **1**




2. Arrow **2** - shows the output of the cooling medium (air + oil).
Arrow **3** - shows the inlet for the power supply cable.




3. Set the interval of cutting oil dispersion on the Microniser- **arrow 4** (3-20 pulses / min.). Adjust this interval to the parameters of the saw band and cut material.



4. Adjust the amount of oil with a regulator - arrow **5**



5. Setting the air quantity using another regulator - arrow **6**



6. Switching on / off of the Microniser is depends on the control system of the machine it is installed on. See chapter "Machine control".

Recommended cutting oils for Micronisation:

Manufacturer	Cutting oil
Biona	Biocut
Paramo	Paramo cut 22

Featured are cutting oils with viscosity class 22.I

Adding of the coolant is possible after removing the filling cap. After the filing is finished the cap must be screwed in again.

Package Includes: a tank with regulators, connection 6m hose, diffuser.

4.9.3. Connecting to the compressed air supply

Connect the machine to the compressed air supply by means of the G1/4 screwing.

Compressed air must satisfy conditions:

- Roughly cleaned and partly dry
- $p_{\min} = 0,4 \text{ MPa}$
- $p_{\max} = 0,6 \text{ MPa}$

4.10. Chips disposal

Chips resulting from cutting operations must be disposed of in accordance with the relevant regulations.

- Let the chips drip excess fluid!
- Fill a watertight container with the chips! Be careful that the container does not leak, because even after a long dripping time, they still contain coolant residue.
- *Place the container into the care of a disposal company equipped for the disposal of chips contaminated with cooling liquid.* In case the machine is equipped with micro-spray installation, the chips must also be handed over to a disposal company.

4.11. Hydraulic, Greases and oils

4.11.1. Gearbox oils

In gearboxes, oil is used for the whole lifetime of the gearbox. We recommend replacing of the filling oil in case of repair.

Use oils with specification DIN 51517 in the gearboxes. Select the viscosity grade ISO VG according to the original oil fill.

Attention:

When replacing, use oils recommended by BOMAR or oils, which has comparable parameters from the other manufacturers. Do not forget, that mineral and synthetic oils must not be mixed!

Recommended oils and quantity according to the type of the band saw

Band saw	Gearbox oil	Capacity
Individual 520.360 DGH	Shell Tivela S 320	3,3 l
Swarf conveyor	Shell Tivela S 320	0,075 l

Comparative table of the gearbox oils

Manufacturer	Viscosity grade		
	ISO VG 100	ISO VG 220	ISO VG 320
BP	Energol GR-XP 100	Energol GR-XP 220	Energol GR-XP 320
Castrol	Alpha SP 100 Alpha MW 100	Alpha SP 220 Alpha MW 220	
Elf	Reductelf SP 100	Reductelf SP 220 Reductelf Synthese 220	Reductelf SP 320
Esso	Spartan EP 100	Spartan EP 220	Spartan EP 320
Mobil	Mobilgear 627	Mobilgear SHC 220 Mobilgear 630	Mobilgear 632
ÖMV		PG 220	
Paramo	PP 7	Paramo CLP 220	Paramo CLP 320
Shell	Shell Omala 100	Shell Omala 220 Shell Tivela S 220	Shell Omala 320 Shell Tivela S 320
Total	Carter EP 100	Carter EP 220	Carter EP 320

4.11.2. Lubricant greases



We recommend using lithium based saponified grease, class NGLI-2 for lubrication. Different greases are mixable, if their oil bases and consistence type are identical.

Comparative table of the lubricant greases:

Manufacturer	Type of the lubricant grease
BP	Energrease LS - EP
DEA	Paragon EP1
Esso	FETT EGL 3 144
	Beacon EP 1
	Beacon EP 2
FINA	FINA LICAL M12
Klüber	Microlube GB0
	Staburags NBU8EP
	Isoflex Spezial
Optimol	Optimol Longtime PD 0, PD1, PD2
Shell Aseol AG	ASEOL Litea EP 806-077
Texaco	Multifak EP1

4.11.3. Lubrication

There are several places on the machine, which are necessary to grease periodically. It secures the right function of the machine.

Lubrication place	Lubrication
	The guiding cubes leading – grease with oil from both sides once a week.
	The linear guiding of the saw arm – lubricate with grease once a three months (see chapter Lubricant greases). Use 3-5g grease on the every carriage of the linear guiding. Use the grease gun to the lubrication. Drive 3-5 times whole line of the linear guiding during lubrication.

4.11.4. Hydraulic oils

Replace the hydraulic oil once in 2 years, because the oil can deteriorate its properties and cause problems the hydraulic equipment. If the hydraulic system is equipped with filter (2SF 56/48-0,063), replace the filter too.

Use oils with specification DIN 51524-HLP, ISO 6743-4 and viscosity grade ISO VG 46 in hydraulic aggregates. Hydraulic oils quantity – see chapter **Hydraulic oil level check**.

Note:

When replacing, use oils recommended by BOMAR or oils, which has comparable parameters from the other manufacturers. Do not forget, that mineral and synthetic oils may not be mixed!


Comparative table of the hydraulic oils

Manufacturer	Type	Manufacturer	Type
Agip	Oso 46	Ina	Hidraol 46 HD
Aral	Vitam GF 46	Klüber	Lamora HLP 46
Avia	Avilub RSL 46	Hungary	Hidrokomol P 46
Benzina	OH-HM 46	Mobil	Mobil DTE 25
BP	Energol HLP 46	ÖMV	HLP 46
Bulgaria	MX-M/46	Poland	Hydrol 30
Castrol	Hyspin AWS 46	Rumania	H 46 EP
Čepro	Mogul HM 46	Russia	IGP 30
DEA	Astron HLP 4hy6	Shell	Tellus Oil 46
Elf	Elfolna 46	Sun	Sunvis 846 WR
Esso	Nuto H 46	Texaco	Rando HD B 46
Fam	HD 5040	Valvoline	Ultramax AW 46

Manufacturer	Type	Manufacturer	Type
Fina	Hydran 46		

4.11.5. Hydraulic unit service

After 50 hours working time, or the latest 3 month after the first run, the first service should be carried out. This includes:



- checking off all screws and connections, fixing points, tubes and hoses for leakage
- Check hydraulic oil level
- During time of duty the oil temperature shouldn't exceed 60-70°C
- check function of signaling components (thermometer, level gauge, dirty filter indicator)
- Check the adjustment of working pressure

To realise a high reliability of the power pack, the manufacturer lays down following inspection intervals

Interval	daily	weekly	monthly	three monthly	six monthly	annually
Hydraulic fluid						
Level	-	•	-	-	-	-
Temperature	-	•	-	-	-	-
Condition	-	-	•	-	-	-
Change interval	-	-	-	-	-	•
Filter						
Change interval	-	-	-	-	-	-
Other checks						
External Leakages	•	-	-	-	-	-
Contamination	•	-	-	-	-	-
Damages	•	•	-	-	-	-
Noise-(level)	•	-	-	-	-	-
Gauges	-	-	•	-	-	-

4.12. Machine cleaning

Clean the machine from the cooling liquid and impurities after every shift stopping. Conserve the guiding surfaces, mainly.

- Clamping jaws guiding of the vice.
- The guiding of the feeder.
- Loading surface of the vice.

4.13. Worn pieces replacement

4.13.1. Hard metal guides replacement

If the hard metal guides cannot be adjusted, they have to be replaced.

ATTENTION!

Hard metal guides must be replaced together on both guiding cubes!


1. Disconnect the cooling liquid inlet; dismount the saw band and the saw band guide cube. Dismount the holder with cooling and regulation from the guide cube with the thrust-to-cut control device..



2. Loosen the binding screws of the fixed holder of hard metal guides and remove the holder.



3. Loosen the binding screws of the adjustable holder of hard metal guides.



4. Through the hole in the opposite wall, release the lock ring which retains the setting screw of the adjustable holder of hard-metal guide



5. Dismount the setting screw of the adjustable holder of hard-metal guides and remove the holder.
6. Insert new hard metal guides, fix them firmly.
7. Mount the guide cube on the machine. Mount the holder with cooling and regulation on the guide cube with the thrust-to-cut control device.
8. Mount the saw band and connect the cooling.
9. Set the hard metal guides on the machine.


4.13.2. Hard metal guides adjustment on the machine

After replacement of the saw band and mounting of the guide cubes on the machine, it is necessary to adjust the hard metal guides on the machine.

Correct adjustment of the hard metal guides has a great influence on cutting accuracy and life of the saw band.

Set the hard metal guides on both of the guide cubes simultaneously!

1. Carefully tighten the setting screw of the adjustable holder of hard-metal guides on the guide cube to release the saw band.
2. Then loosen the screw slowly, until the hard-metal plate touches the saw band. It must be possible to turn the screw by hand freely.
3. In the same way, set the hard-metal guides on the right cube as well.



4.13.3. Saw band guiding pulleys replacement

If the saw band is not sufficiently guided by guiding pulleys or if the pulleys are obviously worn, the pulleys should be replaced.

ATTENTION!

Guiding pulleys must be replaced together on both guiding cubes!!

1. Disconnect the cooling liquid inlet; dismount the saw band and the saw band guide cube. Dismount the holder with cooling and regulation from the guide cube with the thrust-to-cut control device.



2. Fasten the guide cube in the vice; then dismount both eccentrics with bearings in the described way.

Caution!

Mark the location of both eccentrics and parts on the eccentric! The eccentrics are not interchangeable!

10.

3. Dismount the nuts from the eccentrics.



4. Remove eccentrics from bearings by means of the swager and pull them out from the cube.



5. Change all worn bearings and others worn parts.



6. Install eccentrics to the cubes. Install components on both eccentrics in given order. Put bearings by means of the preparation on eccentrics.

ATTENTION!
Do not replace the eccentrics placing in the cube




7. Screw on nuts on both eccentrics and tighten them lightly.



8. Now insert a piece of the guide band in the guide cube (approx. 15 – 20 cm). Set the eccentrics with spanners so that the band runs in the middle. The guide rollers must not push on the saw band too much, but they must rotate freely during the saw band run..
9. Tighten the nuts on both eccentrics.
10. Remove the test piece of the saw band from the cube guide.
11. Mount the guide cube on the machine. Mount the holder with cooling and regulation on the guide cube with the thrust-to-cut control device.
12. Mount the saw band and connect the cooling.
13. If it is necessary, set the hard metal guides on the machine..

4.13.4. Pushing bearing replacement

If it is impossible to adjust the bundle gripping assembly and the pushing bearing is worn, it needs to be replaced.



The bearing condition is possible discover, on the cube from the bottom side, for a better inspection is possible to put out the holder of the bearing from the cube.

If the bearing is worn, there is a visible groove on its surface.

Bearing replacement:

1. Disconnect the cooling liquid inlet; dismantle the saw band and the saw band guide cube. Dismount the holder with cooling and regulation from the guide cube with the thrust-to-cut control device.




2. Fasten a dismantled cube into the vice and by means of the Allen wrench release fixative screw of the bearing holder. Remove the bearing holder from the cube
3. Insert the bearing holder to the vice.

Attention:

The vice has to have aluminium jaws, eventually, there has to be an aluminium agent to protect the bearing holder from damage.



4. Remove the bearing pivot from the bearing holder by means of the pusher and remove the parts, which were threaded on the pivot.



5. Check all parts and remove the worn ones. Including the bearings.
6. Fasten the holder to the vice for mounting again for montage.

Attention:

The vice has to have aluminium jaws, eventually, there has to be an aluminium agent to protect the bearing holder from damage.

7. Insert the bearing(s) and (eventually) pushing ring and washers in prescribed order and return the pivot to its original place.

Attention:


The pivot may not extend past the holder; otherwise, the bundle gripping assembly regulator gets worse!

8. Insert the assembled bearing holder into the guide cube and fix it with the grub screw and Allen key.
9. Mount the guide cube on the machine. Mount the holder with cooling and regulation on the guide cube with the thrust-to-cut control device.
10. Mount the saw band and connect the cooling.
11. Set the hard metal guides on the machine if it is necessary.


4.14. Brush replacement

If the chip removing brush is not able to fulfil its function, it has to be replaced.

1. Dismantle the brush cover.



2. Hold the brush shaft, with a spanner, for example



3. Release the nut on the brush, replace worn brush on the new brush, screw on the nut again.
4. Adjust the brush to the saw band.
5. Remount the brush cover.

5. **Závady / Störungen Troubleshooting**

5.1. Mechanical problems

Problem	Possible causes	Repair
1. Slanting cut	- Wrongly adjusted hard metal guides.	Set according to the chapter „Servicing and adjustment“
	- Worn hard metal guides.	Replace to the chapter „Worn pieces replacement“
	- Wrongly adjusted cubes of the saw band guiding.	Set according to the chapter „Servicing and adjustment“
	- Worn bearings of the saw band guiding.	Replace according to the chapter „Worn pieces replacement“
	- Wrongly adjusted swarf brush.	Set according to the chapter „Servicing and adjustment“
	- Worn swarf brush.	Replace according to the chapter „Worn pieces replacement“
	- Insufficient saw band stretching.	Rise the saw band stretching and set the limit switch.
	- Wrongly chosen tooth system of the saw band.	Replace the saw band and keep the instructions of manufacturer on new saw band choice.
	- Worn saw band.	Replace the saw band.
	- Wrongly balanced roller conveyor.	Set the roller conveyor.
	- Dirty feeding board.	Cleanse the feeding board from debris, chip and residue material.
	- Guiding arm and guiding cube are loosened.	Clamp the guiding arm.
	- Guiding arm and cube are too far from the material.	Set the guiding cube to the material.
	- Too fast cutting rate.	Lower the material feeding speed.
	- Unexpected oscillation in material quality.	Set the cut and feeding speed to the relevant material.
1. The cut is not cut upon desired angle	- Securing lever is loosened.	Check the securing lever efficiency and carry out its adjustment according to chapter „Servicing and adjustment“.
	- Set angle does not match the cut angle.	Check the angle adjustment with a protractor and possibly set it according to chapter „Servicing and adjustment“.
	- Insufficient saw band stretching.	Stretch the saw band and set the limit switch according to chapter „Servicing and adjustment“.
	- Guiding arm and guiding cube are loosened.	Fasten the guiding arm and the cube.
	- Dirt between material and clamping jaw.	Cleanse the material and mating jaw.
2. Short lifetime of the saw band	- Insufficient saw band stretching.	Raise the tightening of the saw band set the scanner of saw band tightening according to chapter „Servicing and adjustment“.
	- Worn swarf brush.	Check the swarf brush condition and replace it in case of excessive use as described in chapter „Worn pieces replacement“
	- Wrongly adjusted swarf brush.	Check swarf brush adjustment, set it according to chapter „Servicing and adjustment“
	- Over stretched saw band	Lower stretching of the saw band and set the limit switch of the saw band stretching according to chapter „Servicing and adjustment“
	- Wrongly adjusted hard metal guides.	Check the adjustment of the hard metal guides and carry out adjustment as described in chapter „Servicing and adjustment“
	- Worn hard metal guides of the saw band.	Check the condition of the hard metal guide and if it is too worn, replace hard metal guides according to chapter „Worn pieces replacement“

Problem	Possible causes	Repair
	- Worn saw band guide bearings.	Check guiding bearings and if you notice some sort of excessive damage, replace them according to chapter „Worn pieces replacement“
	- Wrongly adjusted guiding cubes of the saw band.	Set guiding cube according to chapter „Servicing and adjustment“
	- Wrongly adjusted down feed and saw band speed.	Adjust the feeding and speed of a saw band according to values published by saw band manufacturer.
	- Different material quality.	Adjust feeding and speed of a saw band according to desired material (try cut-test).
	- Low-class saw band	Replace the saw band (contact your local accessory supplier for more information)
	- Wrongly chosen saw band tooth system.	Replace the saw band and keep instructions of the manufacturer on the choice.
	- Wrongly adjusted tracking.	Check the space between top of a saw band and driving wheel. Perhaps adjust the tracking as described in chapter „Servicing and adjustment“
3. Insufficient cut output.	- Worn saw band.	Replace the saw band and keep instructions of the manufacturer on the choice.
	- Wrong saw band tooth system.	Replace the saw band and keep instructions of the manufacturer on the choice.
	- Wrongly set down feed and speed of a saw band.	Set feed and speed of a saw band according to values published by saw band manufacturer.
4. The cut is not finished.	- Wrongly adjusted lower stop point of the saw frame.	Check lower limit switch and screw.
	- Stop point surface is messed-up.	Cleanse stop point surface of the limit switch from debris and residue material.
5. By choke is not possible turn	- Metal clamps between valve and panel.	Clamps must be removed and put on the shaft O-Ring about 10x2 mm.
	- Metal clams are in body of valve.	Valve must be cleared or changed.
6. Saw band drive cannot be started.	- Pressure switch is adjusted wrong.	Set the pressure switch according to chapter „Servicing and adjustment“
	- Pressure switch is defective.	Replace defective parts of the pressure switch.
7. The saw bands are cracked.	- In stretching wheel is wrong adjusting geometry.	Adjust distance band from recess wheel c.2 mm according to operating instructions.
	- Hard metal plates of circuit saw band are not adjusting.	Hard metal plates of circuit saw band must be adjusting according to operating instructions.
	- Guiding cubes are not adjusting (bearings + hard metal circuit)	Guiding cubes must be adjusting (bearings + hard metal circuit) according to operating instructions.
	- Bearings of guiding cubes are used (rolling elements are damaged or outside ring of bearing has conical form).	Bearings of guiding cubes must be replaced. Bearings must be adjusting according to operating instructions.
8. Damage tooth system of the saw band	- In gripping the lifting cylinder is backlash.	
	- Squeezed pin upper or downer holder of the lifting cylinder.	Exchange complete upper or downer holder of lifting cylinder.
9. The saw is cut downing.	- Geometry of hardmetal guiding cubes is wrong adjusted.	Hardmetal guiding cubes must be adjusted.
	- Bearings of guiding cubes are used.	Bearings of guiding cubes must be replaced.
10. Cleansing of the saw band is not functional.	- Elastic wheel of the brush drive is worn-down.	Elastic wheel of the brush must be changed.
	- Knurling of the driving wheel is worn-down.	Driving wheel must be changed.
	- The shaft of the brush drive is rusted.	The shaft of the brush must be cleaned and oiled.

Problem	Possible causes	Repair
	- The brush position and the brush cover is adjusted wrong – with the brush cannot be turned.	The brush cover must be posed, in order to the brush can be turned.
11. The saw arm periodically rise and fall during the cut; this cause short lifetime of the saw band.	- Backlash in driving wheel lodgement on the shaft.	Change the driving shaft for a long one, new bearings, distance ring, new driving wheel, spring, two covers on the forehead of the shaft + screws.
	- Worn channel for spring.	

5.2. Electric and hydraulic problems

Problem	Possible causes	Repair
1. Machine is not possible start.	- In socket is not voltage	Line voltage must be checked.
	- Transfer relay is closed (thermal protector)	Each FA relay must be checked.
	- Limit switch of saw band stretching, cover of frame or cover of saw band is not started.	Check of saw band stretching and covers closing.
2. When cut is finished, the frame is not raising.	- Bottom limit switch is adjusted wrong.	Bottom limit switch must be adjusted according to chapter ADJUSTING.
	- In hydraulic (pneumatic) ring is error. HYTOS (BOSCH) is not acting to frame uplift.	Function of magnetic valve must be checked, valve must be closed, voltage of clamps and inductor must be checked.
3. Electric motor and pump are without voltage. Between contactor and thermal protector is not voltage.	- Wrong contactor.	Replace contactor of engine.
4. The indicator of speed saw band is not functional.	- Sensor of speed is not adjusted.	Sensor of speed must be adjusted.
	- Defective display	The display must be changed.
	- Wrong sensor – diode of indicator speed is not light.	Sensor must be changed and adjusted.
5. Protector is switched off from engine hydraulic aggregate MA3 sometimes.	- Into hydraulic system is high working pressure.	Service engineer must reduce the pressure in hydraulic system.
6. The hydraulic aggregate cannot be started	Auxiliary contact on thermo-relay FA1 is defective.	Replace the defective contact on motor starter FA1.
7. Hydraulic aggregate is switched on but the saw arm or the main vice is not functional	- Wrong connection of electrical supply. The electrical phases are connected conversely.	The phases must be switched. Only service engineer can do this.
8. Cooling is not active	Lack of cooling agent.	Fill the tank with cooling agent.
	- Thermal relay is defective	Change the thermal relay
	- Input hosepipe is broken or obstructed.	Check the cooling circuit and perhaps cleanse cooling system.
	- Cooling pump protection is defective	Check the protection of cooling pump if need change it.
	- Cooling pump is defective.	Replace the cooling pump.

5.3. Hydraulic problems

Problem	Possible causes	Repair
1. Hydrogenerator not supplying oil	• reverse rotation	Check the connections of each phase. Reconnect properly connection of the electrical phases.
	• shortage of oil in the tank	Add hydraulic oil
	• Oil viscosity does not correspond prescribed viscosity value	Change hydraulic oil.
	• Hydrogenerator malfunction	Call service
	• Wrong power supply connection.	Check the connections of each phase. Reconnect properly connection of the electrical phases.
2. Hydraulic oil contains bubbles	• Hydraulic circuit is not adequately deaerated	Make deaeration of hydraulic circuit.
	• Low oil level	Add hydraulic oil
	• the pump shaft seals damaged	Call service
3. Increased mechanical noise	• damaged joint drive	Call service
	• damaged or destroyed motor bearings	Call service
	• air intake	Check for leaks.
4. Low pressure, pump supplies oil	• problem in the safety valve	Wrong settings. Check the settings and adjust the safety valve.
	• pump wear	Call service
	• external or internal leakage	Call service
5. Hydrogenerator is seized	• damage by solid particles in oil	Make oil filtration, or call the service.
	• non-prescribed oil	Change hydraulic oil.
	• wrong type of oil	Change hydraulic oil.
	• exceeding the life of the pump	Call service
6. Overheating oil	• cooler malfunction	Check the cooler function or call service.
	• wear the pump, the energy is converted into heat	Call service
7. Hydraulic valve can not be readjusted	• electromagnet has no signal (voltage) - interrupted supply lines	Check again.
	• Electromagnet coil burnt	Replace coil – Call service.
	• spool valve sticking	Replace valve – Call service

Note:

Frequency Inverter

Do install the bandsaw machine at electrical Installation that corresponds recommended technical standards. We recommend to protect the machine using current protectores by characteristics U, able to compensates interchanges of rising current which escapes from filter of Frequency Inverter, so that additional equipments to the machine will not be required than. We don't recommend to protect a machine by a standard protector current, equipped by a smaller type under 100 mA. Standard used is 30 mA because of current escape in accordance of Frequency Inverters fitted on machine. Alternative solutions should be used current protector (FI) by sensitivity of 100 mA.

6. **Schémata / Schemas / Schematics**

6.1. Elektrické schéma / Elektroschema / Wiring diagram

0	1	2	3	4	5	6	7	8	9
 BOMAR, spol. s r.o. Těžební 1236/1 627 00 Brno Czech republic TOPLINE 510.350 DGH V1.3									
 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno		Stroj/Machine/Maschine: TOPLINE 510.350 DGH		Název stránky/Name page/Name seiten: Úvodní strana/Start page/Startseite		Číslo odk./Doc.No./Anzahl der Dokumente.: ES-TL002-201-V1.3 Napájení/Power supply/Einspeisung: 3x400V + PE + N, 50Hz, TN-S Zpracování/Processed /Halt. verarbeitet: Reviz. Datum/Date/Datum: 13.5.2014		List/Page/ Seite: 00 List/Page/ Seite: 21	

Obsah/ Table of contents/ Inhaltsverzeichnis

Stránka/Page/Seite	Název stránky/Name page/Name Seite	Datum/Date/Datum
00	Úvodní strana/Start page/Startseite	13.5.2014
01	Obsah/ Table of contents/ Inhaltsverzeichnis	13.5.2014
02	Kusovník artiklů/ Parts list/ Artikelstückliste	13.5.2014
02.a	Kusovník artiklů/ Parts list/ Artikelstückliste	13.5.2014
02.b	Kusovník artiklů/ Parts list/ Artikelstückliste	13.5.2014
02.c	Kusovník artiklů/ Parts list/ Artikelstückliste	13.5.2014
03	Ovládací panel na rozvaděči/Control panel/Bedienpult	13.5.2014
03.a	Rozmístění prvků v rozvaděči RS1	13.5.2014
04	Silová část / Power part / Feld partie	13.5.2014
04.a	Silová část M1, M5, M7/ Power part M1, M5, M7 / Feld partie M1, M5, M7	13.5.2014
04.b	Silová část M2, M4 / Power part M2, M4 / Feld partie M2, M4	13.5.2014
05	Deska zdroje/Power board/Netzgerat-Platte	13.5.2014
06	Stykače motorů/Motor contactor/Motor-Schutzschalter	13.5.2014
07.a	Hydraulické ventily/Hydraulic valve/Hydroventil	13.5.2014
08	Vstupy/Inputs/Eingänge	13.5.2014
09	Tlačítka ovládací panel/Button control panel/Taste Bedienpult	13.5.2014
10	Bezpečnostní okruhy/Safety circle/Sicherheitsbereich	13.5.2014
11	Frekvenční měnič/Speed controller/Frequenzumrichter	13.5.2014
12	Řídicí systém/Control system/Steuersystem	13.5.2014
12.a	Řídicí systém/Control system/Steuersystem	13.5.2014
13	Příslušenství/Accessories/Zubehör	13.5.2014

 BOMAR , s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: TOPLINE 510.350 DGH	Název stránky/Name page/Name seiten: Obsah/ Table of contents/ Inhaltsverzeichnis	Číslo dok./Doc.No./Anzahl der Dokumente:..	ES-TL00-201-V1.3	List/Page/ Seite: 01
			Název/Power supply/Einspeisung:	3x400V + PE + N, 50Hz, TN-S	List/Pages/ Seiten: 21
			Zpracoval/Processed /Hat verarbeitet:	Pavlik	
			Datum/Date/Datum:	13.5.2014	

Parts list

Device identification	Device description	Type number	Manufacturer	Part number	Quantity	Location (page.column)
-SQ11	Limit switch - 1NO + 1NC	FK 3301-M1	PIZZATO	91.173.015	1	/08.4
-CU1	Touch-sensitive keyboard	31.R230-207	AKI ELECTRONIC spol.s.r.o.	31.R230-207	1	/12.0
-FA1	Manual motor starter - 0.25A	MS116-0,25	ABB	91.045.016	1	/04.a.3
-FA2	Manual motor starter - 1A	MS116-1,00	ABB	91.045.019	1	/04.b.6
-FA4	Manual motor starter - 1A	MS116-1,00	ABB	91.045.019	1	/04.a.5
-SQ1	Inductive limit switch S _N =1,5mm	JPS 30D 081.5 PNOFC	BALLUFF	91.172.009	1	/08.0
-SQ14	Analog sensor of distance - 1-4mm, M12	BAW M12MF2-UAC40F-BP00,2-GS00	BALLUFF	91.172.017	1	/12.a.8
-SN1	Lineare incrementa encoder - 10-30VDC/5V TTL line driver	LMIX2-026-08.0-1-01	ELGO	91.270.006	1	/13.6
-FU1	Tube fuse - 2A/250V, slow, 5x20	T2A/250V	ESKA	91.230.001	1	/04.b.0
-FU2	Tube fuse - 2A/250V, slow, 5x20	T2A/250V	ESKA	91.230.001	1	/05.5
-FU3	Tube fuse - 2A/250V, slow, 5x20	T2A/250V	ESKA	91.230.001	1	/05.6
-FU4	Tube fuse - 6,3A/250V, slow, 5x20	T6,3A/250V	ESKA	91.230.002	1	/05.7
-FU5	Tube fuse - 2A/250V, slow, 5x20	T2A/250V	ESKA	91.230.001	1	/05.9
-RP1	Potentiometer 5k	TP195 4x7/N20A	GES-ELECTRONICS, a.s.	91.283.015	1	/11.3
-RP2	Potentiometer 5k	TP195 4x7/N20A	GES-ELECTRONICS, a.s.	91.283.015	1	/12.a.8
-RP3	Potentiometer 5k	TP195 4x7/N20A	GES-ELECTRONICS, a.s.	91.283.015	1	/12.a.8
-RCF1	RCF filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/04.a.2
-RCF2	RCF filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/04.b.6
-RCF3	RCF filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	2	/04.a.5
-RCF4	RCF filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/03.a.6
-RCF11	RCF filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	2	/04.6
-RCF12	RCF filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	2	/04.7
-RCF13	RCF filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/04.6
-RCF14	RCF filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/04.7
-FA1	Auxiliary Contact Block - 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/04.a.3
-FA2	Auxiliary Contact Block - 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/04.b.6
-FA4	Auxiliary Contact Block - 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/04.a.5
-FU1	Fuse terminal	WK4/THSI5U	WIELAND	91.251.102	1	/04.b.0

The manufacturer reserves right to use an equivalent replacement device.

01

 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Machine: TOPLINE 510.350 DGH	Název stránky/Name page/Name sellent: Kusovník artiklů/ Parts list/ Artikelstückliste		Gllo.doc./Doc.No./Anzahl der Dokumente: ES-TL00-201-V1.3	List/Page/ Seite: 02
		Zpracoval/Processed/Hat verarbeitet: Datum/Date/Datum: 13.5.2014		Název/Power supply/Einspeisung: 3x400V + PE + N, 50Hz, TN-S	List/Page/ Seite: 02

<

The manufacturer reserves right to use an equivalent replacement device.

 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Machine: TOPLINE 510.350 DGH	Název stránky/Name page/Name sheet: Kusovník artiklů/ Parts list/ Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente: ES-TL00-201-V1.3		ListPage/ 024
			Napájení/Power supply/Einspeisung: 3x400V + PE + N, 50Hz, TN-S		ListPage/ 024
			Zpracoval/Processed /Hat verarbeitet:		ListPage/ 21
			Datum/Date/Datum: 13.5.2014		ListPage/ 21

Parts list

Device identification	Device description	Type number	Manufacturer	Part number	Quantity	Location (page.column)
-SB7	Attaching adapter + 1NO	M22-AK10	EATON	91.061.021	1	/13.1
-SB7	Carrier plates Moeller	M22S-ST-X	EATON	91.062.009	1	/13.1
-SB501	Emergency-stop mushroom push - button + 3xNC	YW1B-V4E02R	IDEC	91.060.084	1	/10.2
=OP1-SA1	Head of 3 positional switch	M22-WRK3	EATON	91.060.051	1	/09.3
=OP1-SA1	NO contact for Eaton adapter	M22-K10	EATON	91.061.022	1	/09.3
=OP1-SA1	Attaching adapter + 1NO	M22-AK10	EATON	91.061.021	1	/09.3
=OP1-SB1	Green translucent switch head	M22-DL-G	EATON	91.060.031	1	/09.1
=OP1-SB1	Attaching adapter + 1NO	M22-AK10	EATON	91.061.021	1	/09.1
=OP1-SB2	Attaching adapter + 1NO	M22-AK10	EATON	91.061.021	1	/09.2
=OP1-SB2	Switch head - black	M22-D-S	EATON	91.060.035	1	/09.2
=OP1-SB8	Attaching adapter + 1NO	M22-AK10	EATON	91.061.021	1	/10.3
=OP1-SB8	Yellow translucent switch head	M22-DL-Y	EATON	91.060.053	1	/10.3
=R1-QS1	Disconnecter - 3P,40A	OT40FT3	ABB	91.170.019	1	/04.0
=R1-QS1	Terminal shroud	OTS40T3	ABB	91.170.017	1	/04.0
-SQ21	Safety limit switch - 2xNC	QKS8	KEDU	91.173.012	1	/10.2
-PA1	Cylindric fuse - 12A, 10x38 fast, gG characteristic	PV10 12A gG	OEZ	91.231.007	3	/04.a.1
-PA2	Cylindric fuse - 16A, 10x38 fast, gG characteristic	PV10 16A gG	OEZ	91.230.020	1	/04.b.2
-PA4	Fuse switch disconnecter E-90 - 3P	E 93/32	ABB	91.241.014	1	/05.1
-PA4	Cylindric fuse - 2A, 10x38 fast, gG characteristic	PV10 2A gG	OEZ	91.230.034	3	/05.1
-SQ4	Limit switch - 1NC+1NO, M20, slow	D4N-4A32	OMRON	91.173.010	1	/08.3
-SQ2	Limit switch - 1NO + 1NC, roller, M2, snap action	FR 605-M2	PIZZATO	91.173.009	1	/08.1
-SQ3	Limit switch - 1NO + 1NC, roller, M2, snap action	FR 605-M2	PIZZATO	91.173.009	1	/08.2
-FM2	I / O Easy Connector (44 I / O); B2 CNI, ASD-IF-DS444	ASD-IF-DS444	DELTA ELECTRONICS, INC.	91.143.043	1	/12.a.0
-FM2	5m; low inertia (C3) 100W ~ 750W	ASDBCAEN0005	DELTA ELECTRONICS, INC.	91.995.769	1	/12.a.0
-FM2	5m; low inertia (C3) 100W ~ 750W	ASDBCAPW0305	DELTA ELECTRONICS, INC.	91.995.768	1	/12.a.0
=R1-QS1	Handle switch - black	OHBS2RJ	ABB	91.180.015	1	/04.0
-BM1	Safety relay - 4xNO, 1.5s, 24VDC	RT7 A	ABB	91.051.054	1	/10.4
-CU1	Control circuit	PRO-5-X	Bomar	91.995.221	1	/12.0

The manufacturer reserves right to use an equivalent replacement device.


02.a

 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Machine: TOPLINE 510.350 DGH	Název stránky/Name page/Name sheet: Kusovník artiklů/ Parts list/ Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente: Název/Power supply/Einspeisung: Zpracoval/Processed /Hlt. verarbeitet: Datum/Date/Datum:	ES-TL00-201-V1.3 3x400V + PE + N, 50Hz, TN-S Baulst. 13.5.2014	List/Page/ Seite: 004
					List/Page/ Seite: 21

SB8, HL2	SA1	SB501
----------	-----	-------


02.c


0	1	2	3	4	5	6	7	8	9
RS1									
Stroj/Machine/Machine:				Název stránky/Name page/Name sheet:				Gíslo dok./Doc.No./Anzahl der Dokumente:	
TOPLINE 510.350 DGH				Rozmístění prvků v rozvaděči RS1				ES-TL00-201-V1.3	
BOMAR, s.r.o., Těšební 1236/1, CZ 627 00, Brno								Napájení/Power supply/Einspeisung:	
								3x400V + PE + N, 50Hz, TN-S	
								Dělník/Processed /Hlt. verarbeitet:	
								Pavlik	
								Datum/Date/Datum:	
								13.5.2014	
								List/Page/ Seite: 03.4	
								List/Page/ Seite: 21	




03.a


BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: TOPLINE 510.350 DGH	Název stránky/Name page/Name seiten: Silová část / Power part / Feld partie	Číslo dok./Doc.No./Anzahl der Dokumente: E5-TL100-201-V1.3	Stránka/Page/Seite: 04	Úroveň/Level/Ebene: 13.5.2014	Úroveň/Level/Ebene: 21
--	--	--	--	--	---	--











	Srovnání stroje/Machine: TOPLINE 510.350 DGH		Název stroje/Name page/Name sellant: Hydraulické ventily/Hydraulic valve/Hydroventil		Číslo dok./Doc.No./Anzahl der Dokumente: ES-TL100-201-V1.3		List/Page/ Seite: 07/8	
	BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno		Napájení/Power supply/Einspeisung: 3x400V + PE + N, 50Hz, TNVS		Zpracování/Processed /Hat verarbeitet: Pavla		List/Phase/ Seiten: 21	
	Datum/Date/Datum: 13.5.2014		Přítak upnout Upper vice clamp Ober Schraubstock spannen		Přítak povolit Release upper vice Ober Schraubstock lösen		Kontrolka start Indicator start Kontrolllicht start	
	Svěrák upnout Vice clamp Schraubstock spannen		Svěrák povolit Release vice Schraubstock lösen		Napnout pás Sawblade tension Spannen des Sägebandes		Uvolnit pás Sawblade leave Entspannen des Sägebandes	












6.2. Hydraulické schéma / Hydraulikschema / Hydraulic diagram




Poz.	Název položky		ks
Pos.	Bezeichnung		Menge
Pos.	Item		Pcs.
1	Nádrž / Behälter / Tank	TM13,5/S S309-009-1-03 (13 dm3)	1
2	Elektromotor / Elektromotor / Electromotor	EM 71 0,25kW/3 B 35 400/230V. 50 Hz	1
3	Hydrogenerátor / Hydraulikgenerator / Hydrogenerator	10A2,5X053G	1
4	Zpětný filtr /	W79	1
5	Nalévací zátka / Stopfen / Fill stopper	CPT-MD-FA/1"	1
6	Přepouštěcí ventil / Bypassventil / By pass valve	MO-020/32	1
7	Zpětný ventil /	CVG 14	1
8	Rozváděč / Schaltschrank / Switchboard	DVE03-S01-B3- C24/20/T1-M1+K1	1
9	Hydraulický zámek / Hydraulisches Schloß / Hydraulic lock	PC08-30-0-N	1
10	Rozváděč / Schaltschrank / Switchboard	DVE03-S12-B5- C24/20/T1-M1	1
11	Hydraulický zámek / Hydraulisches Schloß / Hydraulic lock	DC08-40-0-N-25	2
12	Rozváděč / Schaltschrank / Switchboard	DVE03-S04-B5- C24/20/T1-M1	2
13	Redukční ventil / Reduktionventil /	VRN1-06/RV-6,3 92.154.001	2
14	Manometr / Manometer / Manometer	D68, RAD., 0-60 bar	1

7. Výkresy sestav pro objednání náhradních dílů / Zeichnungen für Bestellung der Ersatzteile / Drawing assemblies for spare parts order

- Při objednávání náhradních dílů vždy uvádějte: typ stroje (např. practix Individual 520.360 DGH) , výrobní číslo (např. 125) a rok výroby (např. 1999).
- In die Bestellung der Ersatzteile führen Sie immer an: Maschinentyp (z. B. Individual 520.360 DGH), Serien Nr. (z. B. 125) und Baujahr (z. B. 1999).
- For spare parts order, you must always to allege: type of machine (for example Individual 520.360 DGH), serial number (for example 125, see cover page) and year of construction (for example 1999).

7.1. TOPLINE 510.350 DGH




NAZEV SESTAVY PILA PASOVA	CISLO SESTAVY 201.TL300-100	STROJ TL350DGH
Konstruoval: ODVARKA		
Datum: 21. 11.2013		
Měřítko: 1:50		

7.2. Kusovník / Piece list / Stückliste - TOPLINE 510.350 DGH

Císlo Sestavy 201.TL300-100		Ver. 0	Název sestavy PILA PASOVA/BAND SAW/BANDSAGE		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.TL301-100	0	PODSTAVEC / BASE / UNTERSATZ		1
2	201.TL302-050	0	BRZDA / DRIVE / ANTRIEB		1
3	201.TL302-100	0	KONZOLA OTOCNA / TURNABLE CONSOL / DREHKONSOLE		1
4	201.TL303-000	0	SVERAK / VICE / SCHRAUBSTOCK	SESTAVA	1
5	201.TL304-000	0	RAMENO / SAW ARM / SÄGERAHMEN		1
6	201.TL305-100	0	POHON / CART / WAGEN	SESTAVA	1
7	201.TL309-000	0	PODSTAVEC SVERAKU / VICE BASE / SCHRAUBSTOCKUNTERSATZ		1
8	201.TL309-020	0	BRZDA / BRAKE / BREMSE		1
9	201.TL330-000	0	OVLADACI PANEL / CONTROL PANEL / BEDIENPULT		1
10	30.TL314-250	0	OKAP / GUTTER CHANNEL / BLECH		1
11	30.TL314-260	0	OKAP / GUTTER CHANNEL / BLECH		1
12	30.TL399-001	0	STITEK / LABEL / SCHILD	P 0.5x65	1
13	31.0599-005	0	SAMOLEPKA / STICKER / AUFKLEBER		2
14	92.001.085	0	AGREGAT HYDRAULICKY / HYDRAULIC GENERATOR / HYDRAULIKAGGREGAT		1
15	99.900.040	0	SAMOLEPKA / STICKER / AUFKLEBER		1
16	99.900.043	0	SAMOLEPKA / STICKER / AUFKLEBER		1
17	99.900.045	0	SAMOLEPKA / STICKER / AUFKLEBER		1
18	99.900.046	0	SAMOLEPKA / STICKER / AUFKLEBER		1
19	99.900.047	0	SAMOLEPKA / STICKER / AUFKLEBER		1
20	99.900.048	0	SAMOLEPKA / STICKER / AUFKLEBER		1
21	99.900.049	0	SAMOLEPKA / STICKER / AUFKLEBER		1
22	99.900.053	0	SAMOLEPKA / STICKER / AUFKLEBER		1
23	99.901.032	0	SAMOLEPKA / STICKER / AUFKLEBER	CETIFIKACNI SAMOLEPKA	1
24	99.901.065	0	SAMOLEPKA / STICKER / AUFKLEBER		1

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.3. TOPLINE 510.350 DGH




NAZEV SESTAVY PILA PASOVA	CISLO SESTAVY 201.TL300-100	STROJ TL350DGH
Konstruoval: ODVARKA		
Datum: 21. 11. 2013		
Meritko: 1:50		

7.4. Kusovník / Piece list / Stückliste - TOPLINE 510.350 DGH

Císlo Sestavy 201.TL300-100		Ver. 0	Název sestavy PILA PASOVA/BAND SAW/BANDSAGE		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.TL301-100	0	PODSTAVEC / BASE / UNTERSATZ		1
2	201.TL302-050	0	BRZDA / DRIVE / ANTRIEB		1
3	201.TL302-100	0	KONZOLA OTOCNA / TURNABLE CONSOL / DREHKONSOLE		1
4	201.TL303-000	0	SVERAK / VICE / SCHRAUBSTOCK	SESTAVA	1
5	201.TL304-000	0	RAMENO / SAW ARM / SÄGERAHMEN		1
6	201.TL305-100	0	POHON / CART / WAGEN	SESTAVA	1
7	201.TL309-000	0	PODSTAVEC SVERAKU / VICE BASE / SCHRAUBSTOCKUNTERSATZ		1
8	201.TL309-020	0	BRZDA / BRAKE / BREMSE		1
9	201.TL330-000	0	OVLADACÍ PANEL / CONTROL PANEL / BEDIENPULT		1
10	30.TL314-250	0	OKAP / GUTTER CHANNEL / BLECH		1
11	30.TL314-260	0	OKAP / GUTTER CHANNEL / BLECH		1
12	30.TL399-001	0	STÍTEK / LABEL / SCHILD	P 0.5x65	1
13	31.0599-005	0	SAMOLEPKA / STICKER / AUFKLEBER		2
14	92.001.085	0	AGREGAT HYDRAULICKÝ / HYDRAULIC GENERATOR / HYDRAULIKAGREGAT		1
15	99.900.040	0	SAMOLEPKA / STICKER / AUFKLEBER		1
16	99.900.043	0	SAMOLEPKA / STICKER / AUFKLEBER		1
17	99.900.045	0	SAMOLEPKA / STICKER / AUFKLEBER		1
18	99.900.046	0	SAMOLEPKA / STICKER / AUFKLEBER		1
19	99.900.047	0	SAMOLEPKA / STICKER / AUFKLEBER		1
20	99.900.048	0	SAMOLEPKA / STICKER / AUFKLEBER		1
21	99.900.049	0	SAMOLEPKA / STICKER / AUFKLEBER		1
22	99.900.053	0	SAMOLEPKA / STICKER / AUFKLEBER		1
23	99.901.032	0	SAMOLEPKA / STICKER / AUFKLEBER	CETIFIKACNÍ SAMOLEPKA	1
24	99.901.065	0	SAMOLEPKA / STICKER / AUFKLEBER		1

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednáci číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.5. Topline 510.350 DGH s automatickým natáčením úhlu ramene



NAZEV SESTAVY PILA PASOVA	CÍSLO SESTAVY 201.TL300-200	STROJ TL350DGH
Konstruoval: ODVARKA		
Datum: 23. 04.2014		
Měřítko: 3:50		


S AUTOMATICKÝM NATÁČENÍM KONZOLY A PRESUNEM SVĚRAKU

7.6. Kusovník / Piece list / Stückliste - Topline 510.350 DGH s automatickým natáčením úhlu ramene

Císlo Sestavy 201.TL300-200		Ver. 0	Název sestavy PILA PASOVA/BAND SAW/BANDSAGE		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.TL301-100	1	PODSTAVEC / BASE / UNTERSATZ		1
2	201.TL302-100	1	KONZOLA OTOCNA / TURNABLE CONSOL / DREHKONSOLE		1
3	201.TL303-000	0	SVERAK / VICE / SCHRAUBSTOCK	SESTAVA	1
4	201.TL304-000	0	RAMENO / SAW ARM / SÄGERAHMEN		1
5	201.TL305-100	0	POHON / CART / WAGEN	SESTAVA	1
6	201.TL309-000	1	PODSTAVEC SVERAKU / VICE BASE / SCHRAUBSTOCKUNTERSATZ		1
7	201.TL314-100	1	POHON / DRIVE / ANTRIEB		1
8	201.TL330-000	1	OVLADACÍ PANEL / CONTROL PANEL / BEDIENPULT		1
9	30.TL314-250	0	OKAP / GUTTER CHANNEL / BLECH		1
10	30.TL314-260	0	OKAP / GUTTER CHANNEL / BLECH		1
11	30.TL399-001	0	STÍTEK / LABEL / SCHILD	P 0.5x65	1
12	31.0599-005	0	SAMOLEPKA / STICKER / AUFKLEBER		2
13	92.001.085	0	AGREGAT HYDRAULICKÝ / HYDRAULIC GENERATOR / HYDRAULIKAGGREGAT		1
14	99.900.040	0	SAMOLEPKA / STICKER / AUFKLEBER		1
15	99.900.043	0	SAMOLEPKA / STICKER / AUFKLEBER		1
16	99.900.045	0	SAMOLEPKA / STICKER / AUFKLEBER		1
17	99.900.046	0	SAMOLEPKA / STICKER / AUFKLEBER		1
18	99.900.047	0	SAMOLEPKA / STICKER / AUFKLEBER		1
19	99.900.048	0	SAMOLEPKA / STICKER / AUFKLEBER		1
20	99.900.049	0	SAMOLEPKA / STICKER / AUFKLEBER		1
21	99.900.053	0	SAMOLEPKA / STICKER / AUFKLEBER		1
22	99.901.032	0	SAMOLEPKA / STICKER / AUFKLEBER	CETIFIKACNÍ SAMOLEPKA	1
3	99.901.065	0	SAMOLEPKA / STICKER / AUFKLEBER		1

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.7. Topline 510.350 DGH s automatickým natáčením úhlu ramene




NAZEV SESTAVY PILA PASOVA	CÍSLO SESTAVY 201.TL300-200	STROJ TL350DGH
Konstruoval: ODVARKA		
Datum: 23. 04.2014		
Měřitko: 3:50		

7.8. Kusovník / Piece list / Stückliste - Topline 510.350 DGH s automatickým natáčením úhlu ramene

Císlo Sestavy 201.TL300-200		Ver. 0	Název sestavy PILA PASOVA/BAND SAW/BANDSAGE		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.TL301-100	1	PODSTAVEC / BASE / UNTERSATZ		1
2	201.TL302-100	1	KONZOLA OTOCNA / TURNABLE CONSOL / DREHKONSOLE		1
3	201.TL303-000	0	SVERAK / VICE / SCHRAUBSTOCK	SESTAVA	1
4	201.TL304-000	0	RAMENO / SAW ARM / SÄGERAHMEN		1
5	201.TL305-100	0	POHON / CART / WAGEN	SESTAVA	1
6	201.TL309-000	1	PODSTAVEC SVERAKU / VICE BASE / SCHRAUBSTOCKUNTERSATZ		1
7	201.TL314-100	1	POHON / DRIVE / ANTRIEB		1
8	201.TL330-000	1	OVLAĐACÍ PANEL / CONTROL PANEL / BEDIENPULT		1
9	30.TL314-250	0	OKAP / GUTTER CHANNEL / BLECH		1
10	30.TL314-260	0	OKAP / GUTTER CHANNEL / BLECH		1
11	30.TL399-001	0	STÍTEK / LABEL / SCHILD	P 0.5x65	1
12	31.0599-005	0	SAMOLEPKA / STICKER / AUFKLEBER		2
13	92.001.085	0	AGREGAT HYDRAULICKÝ / HYDRAULIC GENERATOR / HYDRAULIKAGGREGAT		1
14	99.900.040	0	SAMOLEPKA / STICKER / AUFKLEBER		1
15	99.900.043	0	SAMOLEPKA / STICKER / AUFKLEBER		1
16	99.900.045	0	SAMOLEPKA / STICKER / AUFKLEBER		1
17	99.900.046	0	SAMOLEPKA / STICKER / AUFKLEBER		1
18	99.900.047	0	SAMOLEPKA / STICKER / AUFKLEBER		1
19	99.900.048	0	SAMOLEPKA / STICKER / AUFKLEBER		1
20	99.900.049	0	SAMOLEPKA / STICKER / AUFKLEBER		1
21	99.900.053	0	SAMOLEPKA / STICKER / AUFKLEBER		1
22	99.901.032	0	SAMOLEPKA / STICKER / AUFKLEBER	CETIFIKACNÍ SAMOLEPKA	1
3	99.901.065	0	SAMOLEPKA / STICKER / AUFKLEBER		1

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.9. Podstavec / Base / Untersatz



NAZEV SESTAVY PODSTAVEC	CÍSLO SESTAVY 201.TL301-100	STROJ TL350
Konstruoval: ODVARKA		
Datum: 18. 04.2014		
Měřítko: 1:10		

7.10. Kusovník / Piece list / Stückliste - Podstavec / Base / Untersatz


Císlo Sestavy 201.TL301-100		Ver. 1	Název sestavy PODSTAVEC/BASE/UNTERSATZ		
Poz	Objednací číslo	Ver.	Název položky	Rozmer	Ks
1	262.007	0	KONEKTOR / CONNECTOR / STECKVERBINDER		1
2	30.M201-005	2	DRŽAK / HOLDER / HALTER	P 4x173	1
3	30.M201-006	2	DRŽAK / HOLDER / HALTER	P 4x173	1
4	30.R201-056	1	VÍKO / COVER / DECKEL	P 4x100	1
5	30.TL301-005	1	VANA / TANK / WANNE		1
6	30.TL301-008	0	PLECH / PLATE / BLECH	P 4x64	2
7	30.TL301-011	0	PLECH DEROVANY / PERFORATED PLATE / LOCHBLECH	P 1x194	1
8	30.TL301-014	0	KRYT / COVER / ABDECKUNG	P 3x200	1
9	30.TL301-016	1	KRYT / COVER / ABDECKUNG	P 2x377	1
10	30.TL301-101	0	PODSTAVEC / BASE / UNTERSATZ		1
11	31.7217-132	0	TESNENÍ / SEALING / DICHTUNG	TL4X196	1
12	90.015.25.035 ①	0	SROUB IMBUS / /	M12X65	10
13	90.400.52.001 ①	0	ZATKA / PLUG / STOPFEN	M10x1	4
14	91.020.004	0	CERPADLO CHLAZENÍ / COOLING PUMP / KÜHLMITTELPUMPE	230/400V	1
15	91.070.010	0	PRUCHODKA / LEADTHROUGH / DURCHFÜHRUNG	M12x1.5 ČERNA	4
16	91.070.012	0	VYVODKA / BUSHING / TÜLLE	M20x1.5	3
17	91.070.013	0	VYVODKA / BUSHING / TÜLLE	M25x1.5	1
18	91.071.022	0	VYVODKA / BUSHING / TÜLLE		3
19	91.072.016	0	MATICE / NUT / MUTTER		3
20	92.009.001	0	PRUCHODKA / LEADTHROUGH / DURCHFÜHRUNG	24x46	4
21	94.101.039	0	ZASLEPKA / PLUG / BLINDFLANSCH	154x154x4	2
22	95.504.004	0	LOŽISKO / BEARING / LAGER	MTO 32xT ZC	1

I. PRIDANA 4x ZATKA 90.400.52.001, ZRUS. SROUB M12x60 (90.001.25.063) A NAHR. SROUBEM M12x65 (90.015.25.035), 083/ZM099, 18.4.204, ODVARKA

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednáací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.11. Brzda / Drive / Antrieb Topline 510.350 DGH


Cislo Sestavy 201.TL302-050		Ver. 0	Nazev sestavy BRZDA/DRIVE /ANTRIEB		
Poz.	Objednaci cislo	Ver.	Nazev polozky	Rozmer	Ks
1	30.TL302-051	0	SEGMENT / SEGMENT / SEGMENT	P 12x314	1
2	90.001.25.031	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x16	4
3	90.011.27.016	0	ZAPUSTNY IMBUS / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M8x25	1
4	201.TL302-070	0	BRZDA / BRAKE / BREMSE		1
5	201.TL302-060	0	DORAZ / STOP PIECE / ANSCHLAG		1
6	30.TL302-052	0	KRYT / COVER / ABDECKUNG	P 1,5x253	1
7	30.TL302-053	0	STUPNICE / SCALE / SKALA	P0,5x24	1
8	30.TL302-054	0	UKAZATEL / INDICATOR / ZEIGER	P 1,5x30	1



Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rožmer/Stock size/Abmessung

7.12. Brzda / Brake / Bremse Topline 510.350 DGH


Cislo Sestavy 201.TL302-070		Ver. 0	Název sestavy BRZDA/BRAKE/BREMSE			
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks	
1	30.8602-505	0	PAKA / LEVER / HEBEL		1	
2	30.TL302-071	0	TELESO / BODY / KÖRPER		1	
3	30.TL302-072	0	EXCENTR / CAM / EXZENTER		1	
4	30.TL302-073	0	PLECH / PLATE / BLECH	P 1x30	1	
5	30.TL302-074	0	DESKA / BOARD / PLATTE	HR 75x15	1	
6	30.TL302-075	0	DESKA / BOARD / PLATTE	HR 50x20	1	
7	30.Y302-204	0	KROUZEK DISTANČNÍ / DISTANCE RING / DISTANZRING	TR 30x5	1	
8	30.Y402-027	1	KROUZEK / RING / RING	TR 25x2	1	
9	30.Y402-029	0	DESKA / BOARD / PLATTE	P 3-15	1	
10	90.001.25.008	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5X12	2	
11	90.001.25.033	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x25	3	
12	90.001.25.036	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8X40	2	
13	90.011.27.003	0	SROUB ZAPUSTNÝ / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M5X10	2	
14	94.004.502	0	RUKOJET / HANDLE / GRIFF	D22	1	
15	95.700.003	0	POUZDRO / SLEEVE / BÜCHSE	20X15	1	
16	95.700.004	0	POUZDRO / SLEEVE / BÜCHSE	20X20	1	



Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung


7.13. Doraz / Stop piece / Anschlag Topline 510.350 DGH

Cislo Sestavy 201.TL302-060		Ver. 0	Název sestavy DORAZ/STOP PIECE/ANSCHLAG		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.TL302-061	0	CEP / LUG / BOLZEN	HR 20x20	1
2	30.TL302-062	0	PAKA / LEVER / HEBEL	P 8x45	1
3	31.0206-005	0	PRUŽINA / SPRING / FEDER	2.50x16x90x27	1
4	90.001.25.016	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x12	1
5	90.001.25.049	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x35	1
6	90.001.55.083	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x30	2
7	90.100.55.006	0	MATICE / NUT / MUTTER	MATICE - M10	1
8	90.163.00.004	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	NORD-LOCK	3
9	90.163.00.011	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	NORD-LOCK	1
10	95.001.004	0	LOŽISKO / BEARING / LAGER	6000 2RS	1
11	95.800.006	0	SEGR HRÍDEL. / OUTSIDE SAFETY RING / SICHERUNGSRING AUSSEN	POJISTNÝ KROUŽEK 15	1



Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.14. Konzola otočná / Turnable consol / Drehkonsole




7.15. Kusovník / Piece list / Stückliste - Konzola otočná / Turnable consol / Drehkonsole

Císlo Sestavy 201.TL302-100		Ver. 1	Název sestavy KONZOLA OTOČNÁ/TURNABLE CONSOL/DREHKONSOLE		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.TL302-020	0	SLOUP / POLE / SAULE		1
2	201.TL302-040	0	ODMEROVANI / MEASURING / GEHRUNGSMESSUNG		1
3	201.TL302-110 (1)	0	SLOUP / POLE / SAULE		1
4	30.TL302-002	0	KRYT / COVER / ABDECKUNG	P 0,8x50	1
5	30.TL302-004	0	KRYT / COVER / ABDECKUNG	P 1x320	1
6	30.TL302-031	0	LISTA VODICI / LEAD TRIM / FÜHRUNGSEIESTE		1
7	30.TL302-032	0	KONZOLA / CONSOL / KONSOLE	P 8x80	1
8	30.TL302-101	1	KONZOLA OTOČNÁ / TURNABLE CONSOL / DREHKONSOLE		1
9	41.001.006	0	TRUBKA / TUBE / ROHR	PG48	1
10	90.001.25.048	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10X30	2
11	90.001.25.056	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12x20	2
12	90.001.25.062	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12X50	10
13	90.001.25.083	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8X30	2
14	90.005.55.015	0	SROUB 6HRANNY / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M8X20	2
15	90.100.55.006	0	MATICE / NUT / MUTTER	MATICE - M10	2
16	90.163.00.001		PODLOŽKA / WASHER / UNTERLEGSCHIEBE	M8	2
17	90.163.00.003	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	NORD-LOCK	2
18	90.163.00.004	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	NORD-LOCK	4
19	94.100.008		ZATKA / /	22x1-2,5	6
20	96.003.001	0	TESNENÍ / SEALING / DICHTUNG	VL NBR-350	1

I.ZMENA SLOUPU 201.TL302-010 ZA 201.TL302-110, 083/ZM099, 22.4.2014, ODVARKA

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.16. Sloup / Pole / Säule



NAZEV SESTAVY SLOUP	CISLO SESTAVY 201.TL302-020	STROJ TL350
	Konstruoval: ODVARKA	
	Datum: 20. 11. 2013	
	Meritko: 1:5	


7.17. Kusovník / Piece list / Stückliste - Sloup / Pole / Säule

Císlo Sestavy 201.TL302-020		Ver. 0	Název sestavy SLOUP/POLE/SÄULE		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.TL302-021	0	SLOUP / POLE / SÄULE	SVARENO	1
2	90.001.25.009	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5X16	8
3	90.001.25.029	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8X12	2
4	90.001.25.048	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10X30	4
5	90.302.02.003	0	KUŽEL, KOLIK S ZAV. / TAPER PIN + THREAD / KEGELBOLZEN + GEWINDE	KOLIK 8x36	2
6	94.012.001	0	RUKOJET / HANDLE / GRIFF		1
7	94.012.002	0	ZATKA / PLUG / STOPFEN		2
8	99.200.286	0	VEDENÍ LINEARNÍ / LINEAR GUIDE / LINEARE FÜHRUNG	MSA 20R 490 35/35N	1

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung


7.18. Odměrování / Measuring / Gehrungsmessung

Císto Sestavy 201.TL302-040		Ver. 0	Název sestavy ODMEROVANÍ / MEASURING / GEHRUNGSMESSUNG		
Poz.	Objednací číslo	Ver.	Název položky	Rozmer	Ks
1	30.6114-143	1	DRŽAK / HOLDER / HALTER	P 3x35	2
2	30.TL302-041	0	DORAZ / STOP PIECE / ANSCHLAG	HR 20x12	1
3	91.070.012	0	VÝVODKA / BUSHING / TULLE		2
4	91.173.010	0	SPINACÍ KONČ. S KLADK. / END SWITCH WITH PULLEY / ENDSCHALTER MIT ROLLE	D4N-4A32	2



Císto Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.19. Sloup / Pole / Säule




NAZEV SESTAVY SLOUP	CISLO SESTAVY 201.TL302-110	STROJ TL350
	Konstruoval: ODVARKA	
	Datum: 22. 04.2014	
	Meritko: 1:5	

7.20. Kusovník / Piece list / Stückliste - Sloup / Pole / Säule

Císlo Sestavy 201.TL302-110		Ver. 0	Název sestavy SLOUP/POLE/SÄULE		
Poz.	Objednáci číslo	Ver.	Název položky	Rozměr	Ks
1	30.TL302-013	0	DRŽAK / HOLDER / HALTER	P 4x40	1
2	30.TL302-111	0	SLOUP / POLE / SÄULE	SVARENO	1
3	30.TL302-112	0	DESKA / BOARD / PLATTE	P 20x174	1
4	90.001.25.018	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x20	17
5	90.001.25.033	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x25	3
6	90.001.25.060	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12x40	8
7	90.002.20.028		SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M16x1,5x25	3
8	90.005.55.024	0	SROUB 6HRANNY / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M10x25	1
9	90.005.55.029	0	SROUB 6HRANNY / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M10x60	1
10	90.100.55.006	0	MATICE / NUT / MUTTER	MATICE - M10	2
11	99.200.296	0	VEDENÍ LINEARNÍ / LINEAR GUIDE / LINEARE FUHRUNG	MSA 25x1000 20/20N	1

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednáací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.21. Svěrák / Vice / Schraubstock




NAZEV SESTAVY SVĚRÁK	ČÍSLO SESTAVY 201.TL303-000	STROJ TL350
Konstruoval: ODVARKA		
Datum: 05. 11. 2013		
Měřitko: 1:4		

7.22. Kusovník / Piece list / Stückliste - Svěrák / Vice / Schraubstock

Císlo Sestavy 201.TL303-000		Ver. 0	Název sestavy SVERÁK/VICE/SCHRAUBSTOCK		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.TL303-001	0	TELESO SVERAKU / VICE BODY / SCHRAUBSTOCKKÖRPER		1
2	30.TL303-002	0	LISTA TRECÍ / LEAD TRIM / FÜHRUNGSLEISTE	P 4x20	2
3	30.TL303-003	0	DESKA / BOARD / PLATTE	P 35x100	1
4	30.TL303-004	0	DESKA / BOARD / PLATTE	HR 160x30	1
5	30.TL303-005	0	DESKA / BOARD / PLATTE	HR 160x30	1
6	201.TL307-000	0	VALEC UPÍNACÍ / FIXING CYLINDER / SPANNZYLINDER		1
7	99.201.062	0	VOZÍK LINEÁRNÍHO VEDENÍ / LINEAR GUIDE CART / LINEARFÜHRUNGSWAGEN	MSA20LE	2
8	30.TL303-006	0	STUHL / TABLE / TISCH	P 5x245	1
9	90.001.55.083	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8X30	6
10	30.TL303-008	0	CELIST / JAW / BACKE		1
11	90.001.25.018	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6X20	15
12	30.TL303-009	0	DESKA / BOARD / PLATTE	HR 100x15	1
13	30.TL303-010	0	KOSTKA / CUBE / WÜRFEL	HR 30x30	1
14	99.201.074	0	VOZÍK LINEÁRNÍHO VEDENÍ / LINEAR GUIDE CART / LINEARFÜHRUNGSWAGEN	MSA25LS	1
15	201.DU40-000	0	SPINÁČ TLAKOVÝ / PRESSURE SWITCH / DRUCKSCHALTER		1
16	90.001.25.050	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10X40	4
17	90.001.25.033	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x25	1
18	90.001.25.031	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x16	4
19	99.200.206	0	VEDENÍ LINEÁRNÍ / LINEAR GUIDE / LINEARE FÜHRUNG	MSA25R 640-20/20 N	1
20	90.001.25.010	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5X20	8
21	90.011.27.005	0	ZAPUSTNÝ IMBUS / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M6X12	14
22	95.800.019	0	SEGR HRÍDEL. / OUTSIDE SAFETY RING / SICHERUNGSRING AUSSEN	POJISTNÝ KROUZEK 52	3
23	30.TL303-016	0	STUHL / TABLE / TISCH	P 5x245	1
24	30.TL303-011	0	DRŽÁK / HOLDER / HALTER	P 3x34	1
25	30.TL303-012	0	TYC / POLE / STANGE	SROUB M10	1
26	90.100.55.006	0	MATICE / NUT / MÜTTER	MATICE _ M10	1
27	91.173.007	0	SPINÁČ KONCOVÝ / END SWITCH / ENDSCHALTER	-R1WK	1

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.23. Válec upínací / Fixing cylinder / Spannzylinder



NAZEV SOUSTAVY VÁLEC UPÍNACÍ	ČÍSLO SOUSTAVY 201.TL307-000	STROJ TL350
Konstruoval: ODVARKA		
Datum: 23. 07.2015		
Měřítko: 2:5		


7.24. Kusovník / Piece list / Stückliste - Válec upínací / Fixing cylinder / Spannzylinder

Císlo Sestavy 201.TL307-000		Ver. 0	Název sestavy VALEC UPÍNAČÍ / FIXING CYLINDER / SPANNZYLINDER		
Poz.	Objednávací číslo	Ver.	Název položky	Rozměr	Ks
1	30.0305-202	0	PIST / PISTON / KOLBEN	TYC 45	1
2	30.1107-104	0	VÍKO / COVER / DECKEL	d 45	1
3	30.2107-002	0	PŘÍRUBA / FLANGE / FLANSCH	TYC 45	1
4	30.2107-003	0	VÍKO / COVER / DECKEL	d 45	1
5	30.3407-103	1	REDUCE / REDUCTION / ADAPTOR / REDUKTION	TYC 17	1
6	30.TL307-001	0	VALEC / /	TRUBKA 52/40	1
7	30.TL307-002	0	PISTNICE / /	D 20	1
8	90.001.25.017	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x16	1
9	90.151.50.004	0	PODLOŽKA / WASHER / UNTERLEGSCHLEIBE	PODLOŽKA 6	1
10	95.801.006	0	SEGR DIRA / OUTSIDE SAFETY RING / SICHERUNGSRING AUSSEN	POJISTNÝ KROUZEK 42	1
11	95.801.007	0	SEGR DIRA / OUTSIDE SAFETY RING / SICHERUNGSRING AUSSEN	POJISTNÝ KROUZEK 45	1
12	96.002.006	0	KROUZEK O DYNAMICKY / DYNAMIC O RING / O-RING DYNAMISCH	12x2 NBR 70SH	1
13	96.002.017	0	KROUZEK O DYNAMICKY / DYNAMIC O RING / O-RING DYNAMISCH	34x3 NBR 70SH	3
14	96.041.002	0	TESNĚNÍ / SEALING / DICHTUNG	601-20x28x5	1
15	96.060.002	0	KROUZEK STÍRAČ / SCRAPER RING / ABSTREIFRING	20x28	1
16	96.082.001	0	KROUZEK TESNÍCÍ / SEAL RING / DICHTUNGSRING	10/14x1.5 CU	1


Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednávací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.25. Spínač tlakový / Pressure switch / Druckschalter

Číslo Sestavy 201.DU40-000		Ver. 0	Název sestavy SPINAC TLAKOVÝ/PRESSURE SWITCH/DRUCKSCHALTER		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.DU40-001	0	PRÍLOŽKA / STRAP / LASCHE	P 8x84	1
2	30.DU40-002	0	PRÍLOŽKA / STRAP / LASCHE	P 6x82	1
3	30.DU40-004	0	KRYT / COVER / ABDECKUNG	P 1,5x87	1
4	30.DU50-003	0	TRUBKA / TUBE / ROHR	TR 16x3	4
5	31.DU50-005	0	PRUŽINA / SPRING / FEDER	d 3,00	4
6	90.001.25.091	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8X100	4
7	90.005.55.018	0	SROUB 6HRANNÝ / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M8X35	1
8	90.013.27.002	0	SROUB PULKULATÝ / HALF ROUND BOLT / HALBRUNDSCHRAUBE	M5X6	2
9	90.100.55.005	0	MATICE / NUT / MUTTER	MATICE - M8	1
10	91.172.009	0	SNÍMAC MAGNET. / MAGNETIC SENSOR / MAGNETSENSOR	JPS30D081.5PNOFC	1



7.26. Rameno / Saw arm / Sägerahmen




WYKŁ. BUDOWY RAMENO	CZĘŚĆ BUDOWY 201.TL304-000.TL350	STRONA 11:100
Konstruował: ODVARKA	Datum: 25. 06. 2014	Meritko: 11:100

7.27. Kusovník / Piece list / Stückliste - Rameno / Saw arm / Sägerahmen

Císlo Sestavy 201.TL304-000	Ver. 2	Název sestavy RAMENO / SAW ARM / SÄGERAHMEN			
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.M305-000	1	PREVODOVKA / TRANSMISSION / GETRIEBE		1
2	201.M308-100	0	NAPINANI / TENSIONING / SPANNUNG		1
3	201.TL310-000	1	VEDENÍ PASU / BELT GUIDE / SÄGEBANDFÜHRUNG		1
4	30.1814-011	2	DRŽAK / HOLDER / HALTER	P 3xT6	1
5	30.2904-003	3	KOLO HNACÍ / DRIVE WHEEL / ANTRIEBSRAD	ODLITEK	1
6	30.M304-009	0	KRYT KARTÁČKU / BRUSH COVER / BÜRSTENABDECKUNG		1
7	30.M304-066	0	KRYT PASU / BELT COVER / BANDABDECKUNG		1
8	30.M304-070	0	VENTILATOR / VENTILATOR / VENTILATOR		1
9	30.R304-006	3	PANT / BOARD / PLATTE	PROFIL	2
10	30.R304-007	2	PANT / BOARD / PLATTE	PROFIL	2
11	30.R304-311	0	KRYT / COVER / ABDECKUNG		1
12	30.TL304-001	1	RAMENO / SAW ARM / SÄGERAHMEN		1
13	30.TL304-018	0	KRYT NAPINÁNÍ / TENSIONING COVER / BANDSPANNUNGSABDECKUNG	P 1.5x310	1
14	30.Y304-018	0	TYC ZAVÍTOVÁ / THREADED POLE / GEWINDESTANGE	M10	2
15	44.104.003	0	PAS PÍLOVÝ 330 / SAW BELT / SÄGEBAND	4780x32(4)x0.90	1
16	90.001.25.007	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5x10	2
17	90.001.25.020	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x30	1
18	90.001.25.060	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12x40	2
19	90.100.55.006	0	MATICE / NUT / MUTTER	MATICE - M10	6
20	90.151.50.002	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	PODLOŽKA 12	2
21	90.163.00.003	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	NORD-LOCK	2
22	90.302.02.003	0	KUŽEL, KOLÍK S ZÁV. / TAPER PIN + THREAD / KEGELBOLZEN + GEWINDE	KOLÍK 8x36	2
23	90.307.02.001	0	KOLÍK / PIN / BOLZEN	D6	2
24	91.001.053	0	ELEKTROMOTOR / ELECTRIC MOTOR / ELEKTROMOTOR	H100KW3	1
25	91.173.007	0	SPINÁČ KONCOVÝ / END SWITCH / ENDSCHALTER	-RIWK	1
26	91.173.012	0	SPINÁČ KONCOVÝ / END SWITCH / ENDSCHALTER		1
27	94.202.002	0	REDUKCE / REDUCTION / ADAPTOR / REDUKTION	REDUKCE 6/RI/4"	2
28	96.081.001	0	KROUZEK TESNICÍ / SEAL RING / DICHTUNGSRING	23x15x3	1
29	99.104.002	0	ZÁMEK / LOCK / SCHLOSS	ZÁMEK CLINSKY	2
30	99.170.053	0	RETEZ ENERGII / ENERGY BELT / ENERGIEKETTE	37x26-R50	13
31	99.171.021	0	RETEZ ENERGII / ENERGY BELT / ENERGIEKETTE	37x26	1

Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.28. Rameno / Saw arm / Sägerahmen



WYKŁ. BUDOWY RAMENO	CZĘŚĆ BUDOWY 201.TL304-000.TL350	STRONA 11:100
Konstruował: ODVARKA	Datum: 25. 06. 2014	Meritko: 11:100

7.29. Kusovník / Piece list / Stückliste - Rameno / Saw arm / Sägerahmen

32	99.171.022	0	RETEZ ENERGII / ENERGY BELT / ENERGIEKETTE	37x26	1
33	99.201.045	0	VOZÍK LINEÁRNÍHO VEDENÍ / LINEAR GUIDE CART / LINEARFÜHRUNGSWAGEN	MSA20ESFON	1
34	99.201.046	0	VEDENÍ LINEÁRNÍ / LINEAR GUIDE / LINEARE FÜHRUNG	MSA25E SS FON	2
35	99.260.003	0	VENTIL / VALVE / VENTIL	1/4"	1

1. ZRUSEN KRYT PASU 30.M304-016 A NAHR. 30.M304-066. 090/ZM099 24.4.2014 SLEZACKOVA


2. ZRUSEN VENTILATOR 30.M304-060 A NAHR. 30.M304-070. 120/ZM142 25.6.2014 SLEZACKOVA

Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Nazev sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Nazev položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.30. Převodovka / Transmission / Getriebe


Císlu Sestavy 201.M305-000		Ver. I	Název sestavy PŘEVODOVKA / TRANSMISSION / GETRIEBE	
Poz.	Objednací číslo	Ver.	Název polozky	Rožmer Ks
1	30.1804-010	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	d 70
2	30.2904-005	0	DISTANC / DISTANCE / DISTANZ	TR 55x8
3	30.2904-006	0	PERO / SPRING / FEDER	HR 14x14
4	30.2908-001	1	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	d 50
5	30.M305-003	2	HŘÍDEL / SHAFT / WELLE	d 65
6	30.M305-005	0	PŘÍRUBA / FLANGE / FLANSCH	ODLITEK
7	30.M305-008	0	PERO / SPRING / FEDER	HR 10x8
8	90.005.55.025	0	SROUB 6HRANNÝ / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M10X30
9	90.005.55.035	0	SROUB 6HRANNÝ / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M12X45
10	90.011.27.025	0	ZAPUSTNÝ IMBUS / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M12X25
11	90.011.27.036 (1)	0	ZAPUSTNÝ IMBUS / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M10X25
12	90.150.50.006	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 10.5
13	95.001.027	0	LOŽISKO / BEARING / LAGER	6309 2RS
14	99.001.129	0	PŘEVODOVKA SNEKOVÁ / WORM GEAR TRANSMISSION / SCHNECKENGETRIEBE	

I.ZRUS.1xSROUB M12x25(90.011.27.025) A NAHR.1xSROUBEM M10x25(90.011.27.036). 110/ZM112 25.6.2012 SLEZACKOVA



Císlu Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název polozky/Volume title/Name der Position; Rožmer/Stock size/Abmessung

7.31. Napínání / Tensioning / Spannung




NAZEV SESTAVY NAPÍNÁNÍ	CÍSLO SESTAVY 201.M308-100	STROJ work350
Konstruoval: VINOHRADSKÝ		
Datum: 25. 06. 2012		
Meritko: 3:10		

7.32. Kusovník / Piece list / Stückliste - Napínání / Tensioning / Spannung

Císlo Sestavy 201.M308-100		Ver. 0	Název sestavy NAPINANI/TENSIONING/SPANNUNG		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.0808-001	1	KOSTKA NAPINANI / TENSIONING CUBE / BANDSPANNUNGSWÜRFEL	80x30	1
2	30.0808-002	1	LISTA VODICI / LEAD TRIM / FÜHRUNGSLISTE	30x20	2
3	30.0808-006	1	LISTA / TRIM / LEISTE	HR 30x10	2
4	30.0808-007	0	SROUB / BOLT / SCHRAUBE	M8x60	1
5	30.1708-004	4	DRŽÁK / HOLDER / HALTER	HR 20x8	1
6	30.2908-001	1	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	d 50	1
7	30.2908-103	2	KOLO NAPINACI / TENSIONING WHEEL / UMLENKRAD	ODLITEK	1
8	30.3508-004	1	KROUZEK / RING / RING	d42	1
9	30.4008-001	1	SROUB / BOLT / SCHRAUBE		1
10	30.4808-101	4	CEP NAPINANI / TENSIONING LUG / SPANNUNGSBOLZEN		1
11	30.4808-103	1	KROUZEK DISTANCI / DISTANCE RING / DISTANZRING	d 45	1
12	30.6908-102	1	DRŽÁK / HOLDER / HALTER		1
13	90.001.25.052	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x50	6
14	90.002.20.013	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M12x25	1
15	90.011.27.008	0	ZAPUSTNÝ IMBUS / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M10x20	1
16	90.100.55.005	0	MATICE / NUT / MUTTER	MATICE - M8	1
17	90.300.07.003	0	KOLIK VALC. KAL. / CYLINDRICAL PIN TEMPERED / ZYLINDERSTIFT GEHARTET	KOLIK 16x80	1
18	90.350.07.002	0	PRUŽINA TALIROVA / DISC SPRING / TELLERFEDER	35,5x18,3x2,0x2,8	6
19	95.001.026	0	LOŽISKO / BEARING / LAGER	6307 2RS	2
20	95.800.014	0	SEGR HRIDEL. / OUTSIDE SAFETY RING / SICHERUNGSRING AUSSEN	POJISTNÝ KROUZEK 35	1
21	95.801.013	0	SEGR DIRA. / INSIDE SAFETY RING / SICHERUNGSRING INNEN	POJISTNÝ KROUZEK 80	2

7.33. Vedení pásu / Belt guide / Sägebandführung



NAZEV SESTAVY VEDENÍ PÁSU	ČÍSLO SESTAVY 201.TL310-000	STROJ TL350
Konstruoval: ODVARKA		
Datum: 17. 04.2014		
Měřítko: 33:100		



7.34. Kusovník / Piece list / Stückliste - Vedení pásu / Belt guide / Sägebandführung

Císlo Sestavy 201.TL310-000		Ver. I	Název sestavy VEDENÍ PASU/BELT GUIDE / SÄGEBANDFÜHRUNG		
Poz.	Objednáací číslo	Ver.	Název položky	Rozměr	Ks
1	30.3510-004	0	TRUBKA / TUBE / ROHR	TR 8x 1	2
2	30.9010-003	0	DRŽÁK / HOLDER / HALTER	PL 5x10	2
3	201.TL310-010	I	KOSTKA VODICÍ / LEAD CUBE / FÜHRUNGSKLOTZ		1
4	201.Y310-300	I	KOSTKA VODICÍ / LEAD CUBE / FÜHRUNGSKLOTZ		1
5	30.M210-008	0	LISTA / TRIM / LEISTE	HR 25x6	1
6	30.M310-002	3	LISTA VODICÍ / LEAD TRIM / FÜHRUNGSLISTE	HR 90x20	1
7	30.M310-004	I	KONZOLA / CONSOLE / KONSOLE		1
8	30.M310-056 (1)	0	KRYT PASU / BELT COVER / BANDABDECKUNG	P 2x95	1
9	30.M310-057 (1)	0	KRYT PASU / BELT COVER / BANDABDECKUNG	P 2x95	1
10	30.TL310-001	0	KONZOLA / /		1
11	30.Y310-008		DRŽÁK / HOLDER / HALTER	P3-50	1
12	90.001.25.007	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5x10	2
13	90.001.25.031	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x16	3
14	90.001.25.052	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x50	2
15	90.001.25.105	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x18	6
16	90.002.20.022	0	SROUB STAVEČÍ / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M8x30	2
17	90.101.55.001	0	MATICE / NUT / MUTTER	MATICE M8	2
18	90.150.50.003	0	PODLOŽKA / WASHER / UNTERLEGSCHLEIBE	PODLOŽKA 5,3	2
19	90.163.00.004	0	PODLOŽKA / WASHER / UNTERLEGSCHLEIBE	NORD-LOCK	2
20	90.303.02.021	0	KOLÍK PRUŽNÝ / PIN / BOLZEN	KOLÍK 8x28	2
21	94.008.003	0	PAKA UPÍNACÍ / ATTACHMENT LEVER / SPANNHEBEL	M8x40	1
22	94.202.002	0	REDUKCE / REDUCTION / ADAPTOR / REDUKTION	REDUKCE 6/R1/4"	1
23	94.202.019 (1)	0	REDUKCE / /	WES 6 / R 1/4	1
24	96.081.001	0	KROUZEK TESNICÍ / SEAL RING / DICHTUNGSRING	23x15x3	1
25	99.260.003	0	VENTIL / VALVE / VENTIL	1/4"	1

I. PRIDANA REDUKCE 94.202.019, ZRUS. KRYT 30.M310-006 A NAHR. 30.M310-056, ZRUS. KRYT 30.M310-007 A NAHR. 30.M310-057,
083,090/ZM099, 17.4.2014, ODVARKA

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos./Position/Position;
Objednáací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.35. Kostka vodící / Lead cube / Führungsklotz



NAZEV SESTAVY KOSTKA VODICI	CÍSLO SESTAVY 201.TL310-010	STROJ TL350
Konstruktor: ODVARKA	Datum: 21. 11. 2013	Meritko: 1:1


7.36. Kusovník / Piece list / Stückliste - Kostka vodící / Lead cube / Führungsklotz

Císlo Sestavy 201.TL310-010		Ver. 1	Název sestavy KOSTKA VODÍCÍ / LEAD CUBE / FÜHRUNGSKLOTZ	
Poz.	Objednací číslo	Ver.	Název položky	Rozměr Ks
1	30.2016-006	0	DESKA / BOARD / PLATTE	HR 40x12 1
2	30.C210-403	1	DISTANC / DISTANCE / DISTANZ	TR 16x3 2
3	30.TL310-011	0	KOSTKA VODÍCÍ / LEAD CUBE / FÜHRUNGSKLOTZ	1
4	30.TL310-012	0	DRŽÁK / HOLDER / HALTER	D 28 1
5	30.TL310-013	0	VÍKO / COVER / DECKEL	HR 30x15 1
6	30.TL310-014	0	JEDNOTKA ODMĚROVÁNÍ / MEASURING UNIT / MESSEINHEIT	d 16 f8 1
7	30.TL310-015	0	KOSTKA / CUBE / WURFEL	HR 25x12 1
8	30.Y310-212	2	EXCENTR / CAM / EXZENTER	d 15 2
9	30.Y310-306	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x25 1
10	30.Y310-310	0	DRŽÁK TVRDOKOVU / POA HOLDER / HM-HALTER	1
11	30.Y310-320	0	DRŽÁK TVRDOKOVU / POA HOLDER / HM-HALTER	1
12	90.001.25.009	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5x16 4
13	90.001.25.010	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5x20 3
14	90.001.25.016	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x12 4
15	90.001.25.017	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x16 2
16	90.004.20.002	0	SROUB STAVEČ / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M6x12 1
17	90.011.27.017	0	ZAPUSTNÝ IMBUS / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M6x16 2
18	90.101.55.002	0	MATICE / NUT / MUTTER	MATICE M10 2
19	90.150.50.006	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	PODLOŽKA 10,5 2
20	90.154.50.001	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	10x16x0,1 2
21	90.301.02.009	0	KOLÍK VALCOVÝ / CYLINDRICAL PIN SOFT / ZYLINDERSTIFT WEICH	KOLÍK 10x26 1
22	90.350.02.005	0	PRUŽINA TALIROVÁ / DISC SPRING / TELLERFEDER	20x10.2x1 6
23	90.350.02.030	0	PRUŽINA TALIROVÁ / DISC SPRING / TELLERFEDER	18x8.2x0,7x1,25 10
24	91.172.017	0	SNÍMAC / SENSOR / SENSOR	1
25	95.001.004	0	LOŽISKO / BEARING / LAGER	6000 2RS 1
26	95.001.014	0	LOŽISKO / BEARING / LAGER	6200 2RS 4
27	95.800.002	0	SEGR HRÍDEL. / OUTSIDE SAFETY RING / SICHERUNGSRING AUSSEN	POJISTNÝ KROUZEK 8 1
28	96.060.004	0	KROUZEK STÍRAČ / SCRAPER RING / ABSTREIFRING	12x18 1

I. ZRUS.TAL. PRUŽINY 90.350.02.003 A NAHR 90.350.02.030 A ZMENA POCTU KUSU Z 8 NA 10, 083/ZM099 17.4.2014, ODVARKA

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.37. Kostka vodící / Lead cube / Führungsklotz




NAZEV SESTAVY KOSTKA VODICI	CISLO SESTAVY 201.Y310-300	STROJ IND360
	Konstruoval: HLADIL	
	Datum: 01. 11. 2010	
	Meritko: 4:5	

7.38. Kusovník / Piece list / Stückliste -
Kostka vodičí / Lead cube / Führungsklotz

Číslo Sestavy 201.Y310-300		Ver. I	Název sestavy KOSTKA VODÍČÍ / LEAD CUBE / FÜHRUNGSKLOTZ		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.C210-403	I	DISTANC / DISTANCE / DISTANZ	TR 16x3	2
2	30.Y310-212	0	EXCENTR / CAM / EXCENTER	d 15	2
3	30.Y310-301	I	KOSTKA VODÍČÍ / LEAD CUBE / FÜHRUNGSKLOTZ	HR 80x50	I
4	30.Y310-306	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x25	I
5	30.Y310-310	0	DRŽÁK TVRDOKOVU / POA HOLDER / HM-HALTER		I
6	30.Y310-320	0	DRŽÁK TVRDOKOVU / POA HOLDER / HM-HALTER		I
7	90.001.25.010	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5x20	3
8	90.002.20.016	0	SROUB STAVEČÍ / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M12x10	I
9	90.011.27.017	0	SROUB ZAPUSTNÝ / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M6x16	2
10	90.101.55.002	0	MATICE / NUT / MUTTER	MATICE M10	2
11	90.150.50.006	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 10,5	4
12	90.154.50.001 (1)	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	10x16x0,1	2
13	90.301.07.001	0	KOLÍK VALCOVÝ / CYLINDRICAL PIN SOFT / ZYLINDERSTIFT WEICH	KOLÍK 10x28	I
14	90.350.07.005	0	PRŮŽINA TALIROVÁ / DISC SPRING / TELLERFEDER	20x10.2x1	6
15	95.001.014	0	LOŽISKO / BEARING / LAGER	6200 2RS	5
16	95.800.002	0	KROUZEK POJIST.VNEJŠÍ / OUTSIDE SAFETY RING / SICHERUNGSRING AUßEN	POJISTNÝ KROUZEK 8	I

I. PRIDANA PODLOŽKA 90.154.50.001. 277/ZM294 I.II.2010 SLEZACKOVA

7.39. Pohon / Cart / Wagen



NAZEV SESTAVY POHON	CISLO SESTAVY 201.TL305-100	STROJ TL350
Konstruoval: ODVARKA		
Datum: 29. 04.2014		
Meritko: 33:100		


7.40. Kusovník / Piece list / Stückliste - Pohon / Cart / Wagen

Císlo Sestavy 201.TL305-100		Ver. I	Název sestavy POHON/CART/WAGEN		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.6611-504	0	KOSTKA / CUBE / WÜRFEL	HR 20x10	1
2	30.TL305-101	1	SROUB / BOLT / SCHRAUBE	KUL. SR. 25x5	1
3	30.TL305-103	0	DRŽÁK / HOLDER / HALTER	HR 60x60	1
4	30.TL305-104	0	REDUKCE / REDUCTION / ADAPTOR / REDUKTION	HR 12x12	1
5	90.001.25.018	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x20	10
6	90.001.25.038	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x50	4
7	90.001.25.092	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x14	4
8	90.001.25.197 (1)	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x45	4
9	91.001.226	0	SERVOMOTOR / SERVOMOTOR / SERVOMOTOR	ECMA-C2080	1
10	93.006.007	0	PNEUMATIKA / PNEUMATICS / PNEUMATIK		2
11	93.010.003	0	SROUB / BOLT / SCHRAUBE	M6	1
12	95.860.001	0	HLAVICE MAZACÍ / HEAD / KOPF	KM5	1
13	99.212.034	0	MATICE / NUT / MUTTER	25x5	1
14	99.213.002	0	LOŽISKO / NUT / MUTTER	BK17	1
15	99.280.279	0	SPOJKA / JOINT / KUPPLUNG	EK2-020-A-15-19	1

I.ZRUS.DRŽÁK 30.TL305-102,ZRUS.2XSROUB M8x80(90.001.25.067),4XSROUB M8x60(90.001.25.040)
PRIDAN 4XSROUB M6x45 (90.001.25.197). 083/ZM099 29.4.2014 SLEZACKOVA

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednáací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.41. Podstavec svěráku / Vice base / Schraubstockuntersatz



NAZEV SESTAVY PODSTAVEC SVĚRÁKU	ČÍSLO SESTAVY TL309-000	STROJ TL350
Konstruoval: ODVARKA		
Datum: 18. 04.2014		
Měřítko: 3:10		

7.42. Kusovník / Piece list / Stückliste - Podstavec svěráku / Vice base / Schraubstockuntersatz


Císlo Sestavy 201.TL309-000		Ver. 1	Název sestavy PODSTAVEC SVĚRAKU/VICE BASE /SCHRAUBSTOCKUNTERSATZ		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.TL309-001	1	PODSTAVEC SVĚRAKU / VICE BASE / SCHRAUBSTOCKUNTERSATZ		1
2	30.TL309-002	0	CELIST / BOARD / PLATTE	P 35x176	1
3	30.TL309-003	0	CELIST / BOARD / PLATTE	P 35x176	1
4	30.TL309-004	0	KRYT / COVER / ABDECKUNG	P 1x90	1
5	30.TL309-005	0	KRYT / COVER / ABDECKUNG	P 1x273	1
6	30.TL309-006	0	DORAZ / STOP PIECE / ANSCHLAG	HR 30x30	1
7	30.TL309-007	0	DORAZ / STOP PIECE / ANSCHLAG	HR 30x30	1
8	30.TL309-009	0	DRŽAK / HOLDER / HALTER	HR 25x4	2
9	90.001.25.009	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5x16	10
10	90.001.25.050	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x40	8
11	90.001.25.052	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x50	2
12	90.001.25.078	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x90	2
13	90.005.55.019	0	SROUB 6HRANNY / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M8x40	2
14	90.013.27.004	0	SROUB PULKULATY / HALF ROUND BOLT / HALBRUNDSCHRAUBE	M5x12	6
15	90.100.55.005	0	MATICE / NUT / MUTTER	MATICE - M8	2
16	99.200.358	0	VEDENÍ LINEARNÍ / LINEAR GUIDE / LINEARE FUHRUNG	MSA 200 310 35/35N	2

I.ŽRUSEN DRŽAK 94.204.005 A NAHR.DRŽAKEM 30.TL309-009, 083/7M099, 18.4.2014, ODVARKA

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung


7.43. Brzda / Brake / Bremse Topline 510.350 DGH

Cislo Sestavy 201.TL309-020		Ver. 0	Nazev sestavy BRZDA/BRAKE/BREMSE		
Poz.	Objednaci cislo	Ver.	Nazev polozky	Rozmer	Ks
1	30.TL309-021	0	KOSTKA / CUBE / WURFEL	HR 50x20	1
2	30.TL309-022	0	TYC / COVER / ABDECKUNG	D 15	1
3	90.001.25.022	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x40	4
4	90.001.25.042	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x120	1
5	90.100.55.004	0	MATICE / NUT / MUTTER	MATICE _ M6	4
6	90.150.50.004	0	PODLOZKA / WASHER / UNTERLEGSCHIBE	PODLOZKA 6,4	4
	94.008.005	0	KLICKA / HANDLE / KURBEL	M10	1



Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.44. Pohon/ Drive/ Antrieb Topline 510.350 DGH-A



NAZEV SESTAVY POHON	CISLO SESTAVY 201.TL314-100	STROJ TL350
Konstruoval: ODVARKA		
Datum: 22. 04.2014		
Měřítko: 1:4		


7.45. Kusovník / Piece list / Stückliste - Pohon/ Drive/ Antrieb Topline 510.350 DGH-A

Císlo Sestavy 201.TL314-100		Ver. 1	Název sestavy POHON/DRIVE / ANTRIEB		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.TL314-020	0	POHON / DRIVE / ANTRIEB		1
2	201.TL314-030	0	BRZDA / BRAKE / BREMSE		1
3	201.TL314-040	0	SNIMAC MAGNET. / MAGNETIC SENSOR / MAGNETSENSOR		1
4	201.TL314-050	0	POHON / DRIVE / ANTRIEB		1
5	30.TL314-004	0	DRŽAK / HOLDER / HALTER	P 5x40	1
6	30.TL314-010	0	DRŽAK / HOLDER / HALTER	P 5x50	1
7	30.TL314-011	0	DORAZ / STOP PIECE / ANSCHLAG	HR 25x5	2
8	30.TL314-013	0	KRYT MOTORU / MOTOR COVER / MOTORABDECKUNG	P 1,5x538	1
9	30.TL314-014	0	LISTA / TRIM / LEISTE	HR 18x6	1
10	30.TL314-015	0	SEGMENT / SEGMENT / SEGMENT	P 12x415	1
11	30.TL314-018	0	DRŽAK / HOLDER / HALTER	P 5x84	1
12	30.TL314-019	0	DRŽAK / HOLDER / HALTER	P 3x50	1
13	30.V301-021	0	KOSTKA NAPINÁNÍ / TENSIONING CUBE / BANDSPANNUNGSWÜRFEL	HR 10x10	1
14	30.V301-127	0	DORAZ / STOP PIECE / ANSCHLAG	HR 12x5	1
15	49.200.042	0	RETEZ / CHAIN / KETTE	081 146cl.	1
16	55.800.009	0	PLECH / PLATE / BLECH	P 0,3 - 15	1
17	90.001.25.026	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x65	1
18	90.001.25.031	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x16	4
19	90.011.27.016	0	ZAPUSTNÝ IMBUS / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M8x25	1
20	90.100.55.004	0	MATICE / NUT / MUTTER	MATICE - M6	1
21	90.350.02.001	0	TALÍROVÁ PRUŽINA / DISC SPRING / TELLERFEDER	12,5x6,2x0,5x0,85	10
22	91.070.019	0	VÝVODKA / BUSHING / TÜLLE	M16x1,5	2
23	91.173.011	0	SPINAC KONC.S KLADK. / END SWITCH WITH PULLEY / ENDSCHALTER MIT ROLLE	PZ-FK3302-M1	2
24	91.173.016	0	SPINAC KONCOVÝ / END SWITCH / ENDSCHALTER	KONCAK	1
25	91.271.002	0	PASKA MAGNETICKÁ / MAGNETIC TAPE / MAGNETBAND	ELGO MB20.50	1
26	92.153.107	0	BLOK / BLOCK / BLOCK	S103-281-1	1
27	99.270.046	0	CLANEK SPOJ.-RETEZ / JOINT CUT ELEMENT / KETTENVERBINDUNGSGLIED	081	2

I. DOPLNEN 2x DORAZ S DRAZKOU 30.TL314-011, 083/ZM099, 22.4.2014, ODVARKA

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednávací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.46. Pohon/ Drive/ Antrieb
Topline 510.350 DGH-A



MAVEJ SESTAVY POHON	CÍSLO SESTAVY 201.TL314-020	STROJ TL350
Konstruovala: ODVARKA		
Datum: 21. 11. 2013		
Meritko: 1-2		


7.47. Kusovník / Piece list / Stückliste - Pohon/ Drive/ Antrieb Topline 510.350 DGH-A

Císlo Sestavy 201.TL314-020		Ver. 0	Název sestavy POHON/DRIVE / ANTRIEB		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.1514-503	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	d 30	2
2	30.TL314-021	0	KONZOLA / CONSOLE / KONSOLE		1
3	30.V302-083	0	HRDEL / SHAFT / WELLE	d 22	1
4	30.V302-085	0	KOLO RETEZOVÉ / CHAIN WHEEL / KETTENRAD	Ø81-12t DISK	2
5	30.V302-086	0	KOLO RETEZOVÉ / CHAIN WHEEL / KETTENRAD	Ø81-13t NABOJ	1
6	90.001.25-017	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6X16	4
7	90.001.25-029	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8X12	2
8	90.001.25.033	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x25	4
9	90.002.20-017	0	SROUB STAVECÍ / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M12X16	4
10	90.011.27-005	0	ZAPUSTNÝ IMBUS / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M6X12	2
11	90.150.50.005	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 8,4	2
12	90.163.00.002	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 8	4
13	91.001.239	0	ELEKTROMOTOR / ELECTRIC MOTOR / ELEKTROMOTOR	0.25kW, 4P, B14, 63, 230/400	1
14	95.001.006	0	LOŽISKO / BEARING / LAGER	6002 2RS	2
15	95.810.004	0	PERO TESNE / SPRING / FEDER	PERO 6X6X12	1
16	95.810.034	0	PERO TESNE / SPRING / FEDER	PERO 6X6X50	1
17	99.001.215	0	PREVODOVKA SNEKOVA / WORM GEAR TRANSMISSION / SCHNECKENGETRIEBE	CH 04, P1=70; 63, B14	1

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version); Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos./Position/Position);
Objednávací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.48. Brzda/ Brake/ Bremse Topline 510.350 DGH-A


Cislo Sestavy 201.TL314-030		Ver. 0	Nazev sestavy BRZDA/BRAKE/BREMSE		
Poz.	Objednaci cislo	Ver.	Nazev polozky	Rozmer	Ks
1	30.6007-108	1	PROHLouZENI / /	SK 22	1
2	30.TL314-031	0	DESKA / BOARD / PLATTE	HR 80x30	1
3	30.TL314-032	0	CELIST POHYBLIVA / MOVING JAW / BEWEGliche BACKE	HR 80x40	1
4	30.V307-253	0	PIST / PISTON / KOLBEN	d 40	2
5	30.V307-254	0	STERAC / WIPER / ABSTREIFER	BA18	4
6	90.001.25.036	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x40	6
7	90.001.55.083	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x30	4
8	90.002.20.003	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M5x6	2
9	90.011.21.003	0	SROUB ZAPUSTNY / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M5x10	8
10	96.002.003	0	KROUZEK O DYNAMICKY / DYNAMIC O RING / O-RING DYNAMISCH	6x2	1
11	96.020.005	0	KROUZEK TESNICI / SEAL RING / DICHTUNGSRING	39.2x5.33	2
12	96.082.002	0	TESNENI / SEAL RING / DICHTUNGSRING	13/17x 5 CU	1



Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.49. Snímač magnetický/ Magnetic sensor/ Magnetsensor Topline 510.350 DGH-A


Císlo Sestavy 201.TL314-040		Ver. 0	Název sestavy SNIMAC MAGNET./MAGNETIC SENSOR/MAGNETSENSOR	
Poz.	Objednací číslo	Ver.	Název položky	Ks
1	30.TL314-042	0	DRŽAK / HOLDER / HALTER	P 5x75
2	30.V302-131	0	DRŽAK / HOLDER / HALTER	HR 25x35
3	92.270.018	0	SNIMAC MAGNET. / MAGNETIC SENSOR / MAGNETSENSOR	ELGO
4	31.1605-121	0	PRUŽINA / SPRING / FEDER	1x9.5x12x4
5	30.1504-017	0	STERAC / WIPER / ABSTREIFER	P 0.3x11
6	30.V302-133	0	PERO / SPRING / FEDER	HR 10x6
7	90.150.50.002	0	PODLOŽKA / WASHER / UNTERLESCHEIBE	PODLOŽKA 4,3
8	90.001.25.004	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M4x16
9	90.013.21.002	0	SROUB PULKULATY / HALF ROUND BOLT / HALBRUNDSCHRAUBE	M5x6
10	90.013.21.007	0	SROUB PULKULATY / HALF ROUND BOLT / HALBRUNDSCHRAUBE	M6x10
11	90.001.25.092	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x14



Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung


7.50. Pohon/ Drive/ Antrieb Topline 510.350 DGH-A

Císlo Sestavy 201.TL314-050		Ver. 0	Název sestavy POHON/DRIVE / ANTRIEB		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.TL307-100	0	VALEC POMOCNÝ / AUXILIARY CYLINDER / HILFSZYLINDER		1
2	30.6803-006	0	VÍKO / COVER / DECKEL	TYC 50x12	1
3	90.001.25.042	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x120	1
4	90.001.25.023	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x50	4
5	90.150.50.004	0	PODLOŽKA / WASHER / UNTERLEGSCHLEIBE	PODLOŽKA 6,4	8
6	90.100.55.004	0	MATICE / NUT / MUTTER	MATICE _ M6	4
7	30.TL314-051	0	TRUBKA / TUBE / ROHR	J 80x40x3	1
8	91.172.009	0	SPINAC / SWITCH / SCHALTER	JPS30D081.5PNOFC	2
9	90.001.25.016	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x12	2



Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.51. Válec pomocný/ Auxiliary cylinder/ Hilfzylinder
Topline 510.350 DGH-A




ČÍSLO SESTAVY 201.TL307-100			
		MNOŽSTVÍ	SCHVÁLIL
MERÍTKO: 1:2	DATUM VYDÁNO:		
KONSTR.: ODVARKA	DATUM POZADOVÁNO:		
DATUM: 19. 06. 2013	VYDAL:		
NÁZEV SESTAVY VALEC POMOCNY			

**7.52. Kusovník / Piece list / Stückliste -
Válec pomocný/ Auxiliary cylinder/ Hilfszylinder
Topline 510.350 DGH-A**

Císlo Sestavy 201.TL307-100		Ver. 0	Název sestavy VALEC POMOCNY/AUXILIARY CYLINDER/HILFSZYLINDER		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.6807-103	1	VÍKO / COVER / DECKEL	TYC 35	1
2	30.6807-104	1	VÍKO / COVER / DECKEL	TYC 35	1
3	30.6807-105	0	VÍKO / COVER / DECKEL	TYC 35	1
4	30.6807-203	0	PIST / PISTON / KOLBEN	TYC 35	1
5	30.TL307-101	0	VALEC POMOCNY / AUXILIARY CYLINDER / HILFSZYLINDER	TR 40/30	1
6	30.TL307-102	0	PISTNICE / PISTON ROD / KOLBENSTANGE	d 16	1
7	90.001.25.017	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x16	1
8	92.002.102	0	SROUBENÍ / BOLTING / VERSCHRAUBUNG	S-GEV-8LLR	2
9	95.800.015	0	SEGR HRÍDEL. / OUTSIDE SAFETY RING / SICHERUNGSRING AUSSEN	POJISTNÝ KROUZEK 40	1
10	95.801.026	0	SEGR DIRA / INSIDE SAFETY RING / SICHERUNGSRING INNEN	POJISTNÝ KROUZEK 34	2
11	96.001.008	0	O-KROUZEK STATIC / STATIC O RING / O-RING STATISCH	26x2 NBR 70SH	2
12	96.002.006	0	KROUZEK O DYNAMICKÝ / DYNAMIC O RING / O-RING DYNAMISCH	12x2 NBR 70SH	1
13	96.041.001	0	TESNENÍ / SEALING / DICHUNG	16x24x4 UN	1
14	96.060.001	0	KROUZEK STÍRAČI / SCRAPER RING / ABSTREIFRING	16x22 NBR 70	1
15	96.082.001	0	KROUZEK TESNÍCÍ / SEAL RING / DICHUNGSRING	10/14	2
16	96.900.007	0	TESNENÍ KOMBINOVANÉ / COMBINATION SEALING / KOMBIDICHUNG	PWA100300-720	1

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.53. Ovladací panel / Control panel / Bedienpult



NÁVŠTĚVY	CÍLOVÝ SYSTÉM	STUPEŇ
OVLADACÍ PANEĚ	201.TL330-000.TL	TL
Konstruoval:	ODVARKA	
Datum:	04. 02.2014	
Verze:	1.3:100	

7.54. Kusovník / Piece list / Stückliste - Ovladačí panel / Control panel / Bedienpult

Císlo Sestavy 201.TL330-000		Ver. 1	Název sestavy OVLADACÍ PANEL/CONTROL PANEL/BEDIENPULT			
Poz	Objednací číslo	Ver.	Název položky	Rozměr	Ks	
1	30.6130-012	0	VÍKRO / COVER / DECKEL	P 0.5x 30x30	3	
2	31.6130-008	0	HLAVICE / HEAD / KOPF		3	
3	251.558	0	PANEL / PANEL / PANEL		1	
4	30.R230-010	0	MEZIKUS / INTERMEDIATE PIECE / PASSTÜCK	d 32	3	
5	30.R230-204	0	PLECH / PLATE / BLECH	P 1x220	1	
6	30.R230-206	1	PLECH / PLATE / BLECH	P 1x220	1	
7	30.TL330-001	0	SKRIN / BOX / KASTEN		1	
8	31.R230-207 (1)	0	PANEL ELEKTRO / ELECTRO PANEL / PANEL	P 3x205	1	
9	61.352.001	0	TESNĚNÍ / SEALING / DICHTUNG	TESNĚNÍ 19x10	1	
10	90.100.55.004	0	MATICE / NUT / MUTTER	MATICE - M6	4	
11	90.150.50.004	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 6,4	4	
12	90.150.50.006	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 10,5	4	
13	91.060.030	0	HLAVICE TOTAL STOP / TOTAL STOP HEAD / TASTE TOTAL STOP		1	
14	91.060.031	0	HLAVICE / HEAD / KOPF		1	
15	91.060.035	0	HLAVICE / HEAD / KOPF		1	
16	91.060.051	0	PREPINAC / SWITCH / UMSCHALTER		1	
17	91.060.053	0	HLAVICE / HEAD / KOPF		1	
18	91.071.022	0	VÝVODKA / BUSHING / TÜLLE		3	
19	91.072.016	0	MATICE / NUT / MUTTER		3	
20	91.170.003	0	SPINAC VÁČKOVÝ / CAM SWITCH / SCHALTER	LE2-12-1763	1	
21	91.180.001	0	DESKA SPINACE / ELECTRIC BOARD / PLATINE		1	
22	91.283.015	0	POTENCIOMETR / POTENTIOMETER / POTENTIOMETER	TP 195 4K7/N 20A	3	
23	99.104.002	0	ZAMEK / LOCK / SCHLOSS	ZAMEK ČINSKY	2	

1.ZRUS.SOUCASTI 30.R230-207 A 31.R330-003 A NAHR.31.R230-207. 007/ZM021 4.2.2014 SLEZACKOVA

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung